

Model label: Replacement cell for chlorine generating devices:

86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET Model SJB-HS-11

Replacement cell for the chlorine generating device

86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET Model SJB-HS-11

REGISTRATION NUMBER 32550, *PEST CONTROL PRODUCTS ACT*. This cell must only be used on this model of chlorine generating device.

READ THE LABEL, THE INSTALLATION MANUAL AND OPERATION MANUAL OF THE CHLORINE GENERATING DEVICE device 86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET Model SJB-HS-11 BEFORE USING.

Registrant: INTEX TRADING LTD.,
C/O 9/F Dah Sing Financial Centre, 108 Gloucester Road,
Wanchai, Hong Kong.

Canadian Agent: William Wheeler Agencies
1332 Clifton Street Winnipeg, MB R3E 2V2
Telephone: 204-774-5464

Model label: Chlorine generating devices:

86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET Model SJB-HS-11
CHLORINE GENERATOR

CONTROLS BACTERIA AND ALGAE

In
Swimming Pool (Spa) Waters

Domestic

A maximum of 1098 L of water can be treated with one
86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET Model
SJB-HS-11 unit.

Maximum output of hypochlorous acid equivalent to 0.012 kg of free available chlorine
per day

For spas, a range of 3-5ppm of free available chlorine must be maintained.

READ THE LABEL AND OPERATING MANUAL BEFORE USING

KEEP OUT OF REACH OF CHILDREN

REGISTRATION NO. 32550 *PEST CONTROL PRODUCT ACT*

WARNING: operating 86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE
SET Model SJB-HS-11 without water flow through the cell can cause a build up of
flammable gases which can result in FIRE OR EXPLOSION.

Registrant: Intex Development Co. Ltd.,
C/O 9/F Dah Sing Financial Center,
108 Gloucester Road, Wanchai, Hong Kong
Canadian Agent: William Wheeler Agencies
1332 Clifton Street Winnipeg, MB R3E 2V2
Telephone: 204-774-5464

MANUAL

86IN X86IN X28IN PURESIPA JET AND BUBBLE DELUXE SET

Model SJB-HS-11

110-120V~, 60Hz, 12A

Read, understand, and follow
all instructions carefully before
installing and using this product.

REGISTRATION NUMBER 32550, PEST CONTROL PRODUCTS ACT

DO NOT RETURN PRODUCT TO STORE

To purchase parts and accessories or to obtain non-technical assistance, Visit
www.intexcorp.com

For technical assistance and missing parts call us toll-free (for U.S. and
Canadian Residents): 1-800-234-6839

Monday through Friday, 8:30am to 5:00pm Pacific Time

SAVE THESE INSTRUCTIONS

**Do not forget to try these other
fine Intex products: pools, pool
accessories, in-home toys,
airbeds and boats available at
fine retailers or visit our
website.**

**Due to a policy of continuous product
improvement, Intex reserves the
right to change specifications and
appearance, which may result in
updates to the instruction manual
without notice.**

TABLE OF CONTENTS

Warning	3-4
Parts	5-6
Product Specifications	7
Set-up	7-10
Salt Level Information	11
Operation	12-13
LED Code Chart	14
Maintenance and Chemicals	15-22
Storage	22
Troubleshooting	23-25
Warranty	26

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Danger

- **Risk of Accidental Drowning. Extreme caution must be exercised to prevent unauthorized access by children. To avoid accidents, ensure that children cannot use this spa unless they are supervised at all times.**
- Risk of drowning. Inspect the spa cover regularly for leaks, premature wear and tear, damage, or signs of deterioration. Never use a worn or damaged cover: it will not provide the level of protection required to prevent unsupervised access to the spa by a child.
- Risk of injury. Replace damaged cord immediately. Do not bury cord. Connect to a grounded, grounding type receptacle only.
- Risk of Injury. The suction fittings in this spa are sized to match the specific water flow created by the pump. Should the need arise to replace the suction fittings or the pump, be sure that the flow rates are compatible.
- To reduce the risk of injury, do not remove the suction fittings. Never operate a spa or hot tub if the suction fittings are loose, broken, damaged, cracked or missing. Replace immediately. Never replace a suction fitting with one rated less than the flow rate marked on the original suction fitting.
- To reduce the risk of drowning from hair and body entrapment, install a suction fitting(s) with a marked flow rate that equals or exceeds the flow rate marked on the equipment assembly.
- Make sure the power outlet current and voltage is suitable for the electrical equipment.
- Risk of Electric Shock. Install at least 1.5m (5 feet) from all metal surfaces. As an alternative, a spa may be installed within 1.5m (5 feet) of metal surfaces if each metal surface is permanently connected by a minimum 8.4 mm² (8 AWG) solid copper conductor to the wire connector on the terminal box that is provided for this purpose.
- Risk of Electric Shock. Do not permit any electric appliance, such as a light, telephone, radio, or television, within 1.5m (5 feet) of a spa or hot tub.
- Risk of Electric Shock. Do not use the spa when it is raining, thundering or lightning.

WARNING

- A wire connector is provided on this unit to connect a minimum 8.4 mm² (8 AWG) solid copper conductor between this unit and any metal equipment, metal enclosures of electrical equipment, metal water pipe, or conduit within 1.5m (5 feet) of the unit.
- To reduce the risk of drowning and injury, do not permit children to use this product unless they are closely supervised at all times.
- To reduce the risk of child drowning, attach and lock spa cover after each use.
- To reduce the risk of drowning and injury:
 - a) Never use the spa alone or allow others to use the spa alone.
 - b) Before entering a spa or hot tub, the user should measure the water temperature with an accurate thermometer since the tolerance of water temperature-regulating devices varies.
 - c) The water in a spa should never exceed 40°C (104°F). Water temperatures between 38°C (100°F) and 40°C (104°F) are considered safe for a healthy adult. Lower water temperatures are recommended for young children and when spa use exceeds 10 minutes.
 - d) Pregnant and possible pregnant women should consult a physician before using a spa or hot tub.
 - e) Since excessive water temperatures have a high potential for causing fetal damage during the early months of pregnancy, pregnant or possibly pregnant women should limit spa water temperatures to 38°C (100°F). Do not stay in spa for longer than 10 minutes.
 - f) The use of alcohol, drugs, or medication before or during spa use may lead to unconsciousness with the possibility of drowning.
 - g) Obese persons and persons with a history of heart disease, low or high blood pressure, circulatory system problems, or diabetes should consult a physician before using a spa.
 - h) Persons using medication should consult a physician before using a spa since some medication may induce drowsiness while other medication may affect heart rate, blood pressure, and circulation.
 - i) Check with a doctor before use if pregnant, diabetic, in poor health, or under medical care.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

READ AND FOLLOW ALL INSTRUCTIONS

- j) Exit immediately if uncomfortable, dizzy, or sleepy. Spa heat can cause hyperthermia and unconsciousness. The use of alcohol, drugs, or medication can greatly increase the risk of fatal hyperthermia. The causes, symptoms, and effects of hyperthermia may be described as follows:
Hyperthermia occurs when the internal temperature of the body reaches a level several degrees above the normal body temperature of 37°C (98.6°F). The symptoms of hyperthermia include an increase in the internal temperature of the body, dizziness, lethargy, drowsiness, and fainting. The effects of hyperthermia include failure to perceive heat; failure to recognize the need to exit spa or hot tub; unawareness of impending hazard; fetal damage in pregnant women; physical inability to exit the spa or hot tub; and unconsciousness resulting in the danger of drowning.
- People with infectious diseases should not use a spa or hot tub.

- To avoid injury exercise care when entering or existing the spa or hot tub.
- Always add chemicals to water, never add water to chemicals. Adding water to chemicals may cause strong fumes or violent reactions and hazardous chemical spray.
- Never jump or dive into a spa or any shallow body of water.
- Assembly and disassembly by adults only.
- Always unplug this product from the electrical outlet before removing, cleaning, servicing or making any adjustment to the product.
- The plug must be accessible after product is installed.
- Do not bury the electrical cord. Locate the cord where it will not be damaged by lawn mowers, hedge trimmers and other equipment.
- If the supply cord is damaged, it must be replaced by a qualified electrician in order to avoid a hazard. Use only identical replacement parts when servicing.
- To reduce the risk of electric shock, do not use extension cords, timers, plug adaptors or converter plugs to connect unit to electrical supply; provide a properly located outlet.
- Do not attempt to plug in or unplug this product while standing in water or when your hands are wet.
- Do not leave the spa empty for extended period of time. Do not expose the spa under direct sunshine.
- Adequate drainage system must be provided around the spa to deal with overflow water.
- Do not allow the water in the spa to freeze. Do not turn on the spa when the water is frozen.
- Do not use the spa if damaged in delivery and/or malfunctioning in any fashion. Contact the Intex service center for further direction.
- Never pour water with a temperature higher than 40°C (104°F) into the spa directly.
- Keep all pets away from spa to avoid any damage.
- Do not add bath oil or bath salt to the spa water.
-

WARNING

- This product is provided with a GFCI/RCD located at the end of the power cord. The GFCI/RCD must be tested before each use. Do not use the spa if the GFCI/RCD does not function properly. Disconnect the power cord until the fault has been identified and corrected. Contact a qualified electrician to correct the fault. Do not bypass the GFCI/RCD. There are no serviceable parts inside the GFCI/RCD. Opening the GFCI/RCD will void the warranty.
- Plug the power cord into a grounded electrical socket.
- Press the **RESET** button on the GFCI/RCD.
- Turn on the spa electrical equipment.
- Press the **TEST** button on the GFCI/RCD. The GFCI/RCD indicator should turn off and the electrical equipment should shut off. If the GFCI/RCD indicator does not turn off, and the electrical equipment does not shut off, the GFCI/RCD is faulty. Do not use the spa. Contact a qualified electrician to correct the fault.

Press the **RESET** button on the GFCI/RCD. The indicator on the GFCI/RCD should turn on. If the GFCI/RCD indicator does not turn on, the GFCI/RCD is faulty. Do not use the spa. Contact a qualified electrician immediately to correct the fault

When ordering parts, be sure to quote the model number and part numbers.

SPA SUCTION FITTING

Self-contained spa fittings. – For multiple outlet use only. – Wall mounting only.
Replace suction fittings within 3 installed years. – Tool required: screwdriver.

Spa suction fitting maximum flow rate: 84 gpm (5040 gph)

- Check suction strainer fitting and fasteners for damage or tampering before each use of the spa.
- For service and winterization instructions refer to “Maintenance” and “Storage” sections.
- Read and follow all instructions, save these instructions for future reference.

Maximum seating capacity:	4 adults	6 adults
Water capacity:	795 L (210 gal)	1098 L (290 gal)
Inner/outer diameter:	150/201 cm (59/79 in)	168/218 cm (66.86
Height:	71 cm (28 in)	
Jet pump:	0.9 HP / 120 V / 60 Hz	0.95 HP / 120 V / 60 Hz
Bubble air blower:	1.1 HP / 110-120 V / 60 Hz	
Filter pump flow rate:	1,741 L/hr (460 gal/hr)	
Heater power:	1,300 Watts / 110-120 V / 60 Hz	
Temperature range:	20°C – 40°C (68°F - 104°F	
Temperature rise:	1-1.5°C/hr (2-3°F/hr)	0.5-1°C/hr
Number of Water Jet Nozzles:	4	6
Number of Bubble Jets:	120	140
Spa tub recommended working air pressure:	1.2 psi (0.083 bar)	

Cord-connected spa with pump, heater, water jet, blower, control panel, built-in hard water treatment, and sanitation system.

This product requires a minimum of 13 Amps. If the circuit breaker trips, please check that no other appliances or other large loads are on the same circuit as the spa.

Site preparation and requirements

- The spa can be installed indoor or outdoor. For household use only.
- The spa must be setup on a level, flat and smooth surface that is capable of supporting the maximum load of the filled spa with four adult occupants: weight 1136Kg (2500 lbs); six adults: 1592 kg (3500 lbs).
- Make sure the area is free of sharp objects under or around the spa.
- Provide adequate drainage system around the spa to deal with overflow water and splashes.
- Provide a properly located power outlet to connect the spa and allow easy access for periodic testing of the cord mounted GFCI/RCD.
- Make sure there is enough clearance around the spa for full access to the spa equipment for maintenance and/or service.
- The area shall facilitate draining purposes during long term spa storage.

Additional requirements for indoor installation

- Make sure the floor can support the full weight of the filled spa with the maximum number of occupants. Check with a qualified contractor or a structural engineer to verify this requirement.
- Make sure the floor is water resistant and non-slip surface. Do not install the spa on carpet or other materials that will be damaged by moisture and condensation.
- Do not install the spa indoors on a second floor above finished living space due to the possibility of water and humidity damage.
- Humidity is a natural side effect of indoor spa installation. The room shall be properly ventilated to allow moisture to escape. Install a ventilating system to prevent excess condensation, moisture in the room.

Additional requirements for outdoor installation

- Spa owners may need to comply with local or states laws relating to childproof fencing, safety barriers, lighting, and other safety requirements. Contact your local building code enforcement office for further details.
- Make sure the surface is level, flat, smooth and strong enough to support the full weight of the filled spa.
- Do not setup the spa on grass or dirt, as this increases the amount of debris entering the spa, and damage the spa floor.
- **Do not expose the spa to direct sunlight for extended period of time.**

It is possible to install and leave the spa outside at a temperature not lower than 4°C (39°F) provided the water temperature inside the spa is higher than 4°C (39°F) and the water inside the circulation system, pump, pipe are not frozen. Put a “temp barrier mat” between the spa floor and the ground to prevent heat loss from the bottom of the spa and to provide better heat retention.

Setup the spa with at least 2 persons.

1. Move the entire package to the selected site. Do not drag the spa tub across the ground as this can cause damage and leakage.
Open the carton carefully as this carton can be used to store the spa during long term storage or when not in use.
2. Lay out all the parts on the ground and make sure all the parts are accounted for. For missing or damaged parts contact the appropriate Intex Service Center listed in the separate "Authorized service Centers" sheet.
3. **Safety Sign Card Posting**
4. The Safety Sign card included with the manual shall be posted in an area visible to the users of the spa to alert them of the safety rules and warnings. For replacement of the safety sign card, visit our website at www.intexcorp.com for additional print copies. Laminate the printed safety sign copy for protection from the elements.

Spa Control Unit Assembly

1. Connect the control panel **(3)** cable plug into the receptacle on top of the spa control base and screw in the plug cover firmly by hand (**see drawing 1**). **Note:** Spread the ground cloth with the bubbles facing down over the cleared area where you intend to setup your spa.
2. Screw the control panel bolts **(4)** with the provided bolt wrench **(6)** to secure the control panel (**see drawing 2**).
3. Plug the spa control unit into a grounded electrical outlet.

For indoor inflation:

Inflate the Spa Tub Wall

1. Take out the ground cloth **(19)** and spread it over the cleared area. Then spread out the spa liner over the ground cloth and point the drain valve towards a suitable draining area.
NOTE: Spread the ground cloth with the bubbles facing down over the cleared area where you intend to setup your spa.
2. Unscrew the control base inflation cap **(9)** to reveal the air blower inflation outlet, insert one end of the inflation hose **(7)** into the outlet and turn to the right to lock it (**see drawing 3**).
3. Unscrew the air valve cap to reveal the stem in the up position for inflation. Insert the other end of the inflation hose **(7)** into the valve and turn to the right to lock it in position (**see drawing 4**).
4. Press the button to turn on the control unit panel buttons first. Press the button to inflate the spa tub wall until it is firm to the touch but not hard (**see drawing 5**).
IMPORTANT: Do not over inflate or use high pressure air compressor to inflate.
5. Press the button again to turn it off.
6. Disconnect the inflation hose **(7)** from the air valve and attach the

pressure gauge **(5)** to the air valve. The pressure gauge indicator should be in the green area for a properly inflated spa tub (**see drawing 6**). Repeat previous steps to add more air if necessary.

7. Replace the air valve cap back.

NOTE: The cap is designed to be screwed on and off. Never exert force as this could cause the complete internal inflation system of the valve to come loose. See “Spa Tub Air Valve Fastening” for valve maintenance.

Inflate the Spa Cover Air Bladder

1. Open the inflation valve and insert the inflation hose (7) into the valve ,press to inflate until it is firm to the touch but not hard
2. disconnected the inflation hose **(7)** from the air blower inflation outlet and the valve.
3. Replace the control base inflation cap (9) back, close and recess the inflation valve

NOTE: If there is a need to add some air to the spa tub wall or spa cover air bladder after they have been setup, refer to above “Inflate the Spa Tub Wall” and “Inflate the Spa Cover Air Bladder” sections. The cover air bladder is preinstalled inside the spa cover. If it needs to be reinstalled, place the uninflated air bladder inside the spa cover lip before inflating the bladder.

Deflation

For Spa Tub Wall:

1. Unscrew the cap to reveal the stem, push the stem in and turn 90 degree right to secure it in the down position (**see drawing 8**).
2. Once the deflation is completed, push the stem in and turn 90 degree left to return it to the inflation position.
3. Replace the cap back.

For Cover Air Bladder:

1. Pull valve cap out and squeeze the valve at its base until deflated.
2. Close and recess the valve back.

Spa Control Unit Installation

1. Connect the spa control unit to the spa tub (**see drawing 9**). Hand-tighten the connectors securely. Do not use tools to tighten.
CAUTION: Do not sit, lean, cover or place any objects over the spa control unit.
2. Attach the two filter cartridge housing assemblies to the two outlet grids on the inside of the spa (marked “B”). Inflate the spa tub first before installing filter pump fittings.
ATTENTION! In order to comply with the requirements of the Virginia

Grahame Baker Act, suction outlets cannot be covered while the spa is in use. The Act was intended to address high suction / volume circulation systems but does not exclude low volume systems as used on this spa. Accordingly, remove the filter cartridge assemblies and any other spa cleaning attachment from the spa outlets before spa usage (**see drawing 10**). Re-attach them after usage for water filtration and cleaning.

3. Before filling with water ensure the bottom drain valve caps are securely closed on the inside and outside.
4. Fill the spa tub with freshwater to a level between MIN and MAX marked on the inside of the spa wall. Do not over fill the spa. Never move the spa tub with water inside and/or with the control base attached to the spa as the spa or control base may be damaged.
WARNING: Never pour water with a temperature higher than 40°C (104°F) into the spa directly. It is recommended to fill the spa tub with lukewarm water for quick heating and energy saving.
5. Place the spa cover and spa air bladder (pre-installed in spa cover) over the spa tub, and make sure the spa cover buckles are locked using the key provided after pulling the buckled straps tight.
IMPORTANT: Inspect the spa cover regularly for leak, premature wear and tear or deterioration. Never use a damaged spa cover.
6. Ensure the spa is plugged into a grounded electrical socket and press the button to turn on the control unit panel buttons first. Press the button on the control panel to activate the heater, see "Spa Control Unit Panel" operation section.

IMPORTANT: The following conditions will lead to slow water heating:

- The ambient temperature is lower than 10°C (50°F).
- Outdoor wind speed is above 3.5-5. 4m/s (8-12 mph).
- The jet function is activated when heating the spa water.
- The spa is not properly covered with the spa cover when the water is heating.

The spa comes with a built-in saltwater sanitation system. Common salt (sodium chloride) is made up of two elements, sodium and chloride. During the installation of the device, a measured quantity of salt is dissolved in the SPA water to make it slightly salty. The SPA water flows through the sanitation system's electrolytic cell to produce chlorine. The chlorine dissolves in the water and instantly starts destroying bacteria and algae. It also oxidizes all other organic materials.

• **Which kind of salt to use:**

Use only Sodium Chloride Salts

Use only sodium chloride (NaCl) salt that is at least 99.9% pure. It is also acceptable to use water conditioning salt pellets (the compressed forms of evaporated salt).

However, it will take a longer time for them to dissolve. **Do not use iodized or yellow (yellow prussiate of soda) colored salt.** Salt is added to the SPA water and the electrolytic cell uses the salt to create chlorine. The purer the salt the better the performance of the electrolytic cell.

• **Optimum Salt Levels**

The ideal salt level in the SPA water is between 2000-3000 ppm (parts per million).

The optimal level is 2500 ppm.

A too low salt level will reduce the efficiency of the sanitation system and result in low chlorine production. Too high a salt level may damage the power supply and cause corrosion to metal fixtures and accessories. The salt in the SPA is constantly recycled. The loss of salt is due only to SPA water being physically removed from the

SPA. Salt is not lost due to evaporation.

- **Adding Salt**

1. Switch the JET pump on to start the water circulation.
2. Keep the sanitation system turned off.
3. Evenly spread 2 kg / 4.4 lbs of salt around the inside perimeter of the SPA.
4. Brush the SPA bottom to speed up the dissolving process. Do not allow salt to pile up on the bottom of the SPA. Run the JET pump for one hour to thoroughly dissolve the salt.
5. When all the salt is dissolved, press the sanitizer button to activate the sanitation system (see “Sanitation System Operating Instructions” section), code “003H” is flashing and set the sanitation system to desired operating hours. **NOTE:** DO NOT press any other buttons on the control panel, ensure the heater is off and attach the spa cover during the sanitizing process.

- **Removing Salt if Salt Level is too high**

If too much salt has been added, the unit will beep and display “E92” (see “LED Code Chart”). If this happens, turn off the sanitation system by pressing the ON/OFF button

and unplug the spa. You will need to lower the salt concentration. The only way to do so is to partially drain the SPA and refill it with fresh water. Drain and refill approximately 25% of the SPA water until the “E92” alarm code disappears.

- **Adding Salt if Salt Level is too low**

If not enough salt has been added, the unit will beep and display “E91” (see “LED Code Chart”). If this happens, turn off the sanitation system by pressing the ON/OFF button , unplug the spa and wait 10 seconds. Plug and turn on the spa, add 0.5 kg / 1.1 lbs increment of salt until the “E91” alarm code disappears (see “Adding Salt” section).

On/Off Button: Once the unit is plugged in, use this button to activate the control unit panel buttons. The light next to the button is green when activated. Press this button to turn off all currently activated functions. **NOTE:** The On/Off button may appear as a black button in the center of the control panel.

Heat Button: Use this button to activate the heating system. The pump will heat the spa water until the water temperature reaches the set temperature. When the spa water temperature drops 3.6°C (2°F) below the set temperature the heating system will restart. When the flame icon on the display is red, the heating system is activated. When the flame icon turns green, the water is at the set temperature. The heating system is at rest and the filtration system will continue working nonstop.

NOTE: To stop the filtration system while the heater is at rest mode, press the flame button first and then the filter button. Pressing the flame button only while the heater is at rest mode will turn off the

heating system only and the filtration system will operate for another 24 hours before it turns off automatically.

Celsius/Fahrenheit Toggle button:

The temperature can be displayed in either Fahrenheit or Celsius. The system's default is Fahrenheit.

Temperature Adjustment Buttons: Pressing the

Temperature Increase or Decrease buttons will cause the LED to flash. When flashing you can adjust to the desired temperature setting. If you hold these buttons down the values will rapidly increase or decrease. The new and desired temperature setting will remain on the LED display for 5 seconds to confirm the new value.

NOTE: The default temperature is 20°C (68°F).

NOTE: Temperature adjustment ranges from 20°C (68°F) to 40°C (104°F).

NOTE: Recommend not to set the water temperature more than 38°C (100°F).

Water Filter Button:

This button turns the filter pump on and off. If the heating system is activated the filtration system will automatically start. The water filter icon on the display is green when activated.

Water Jet Button: Use this button to activate the jet massage

system. After 30 minutes of continuous use, the jet massage system will automatically turn off. The water jet icon on the displays is green when activated. The angle of the water jet nozzles inside the spa tub wall can be adjusted manually.

WARNING: Do not run jet system when the cover is attached, air pressure may accumulate inside the spa and cause irreparable damage and bodily harm.

Bubble Button: Use this button to activate the massage

system, which has a 30-minute auto-shutoff feature. The bubble icon on the displays is green when activated.

WARNING: Do not run Bubble system when the cover is attached, air can accumulate inside the spa and cause irreparable damage and bodily harm.

Sanitizer Button: Use this button to activate and set operating hours

for the sanitation system

LED Display: Once plugged in the LED displays the current water temperature automatically.

NOTE: The built-in hard water treatment function works automatically in conjunction with the filtration system.

Jet Nozzle Adjustment

The amount of water and pressure coming out from the jet nozzles can be adjusted by turning the jet nozzle rim clockwise (maximum water output), counterclockwise (low water output) or anything in between. Closing one or 2 jet nozzles will divert more water pressure to the other jet nozzles

1. Activate the sanitation system:

Press the sanitizer button on the control panel, this

will activate the sanitation system as well as the filter pump. The sanitizer icon and the filter icon turn green. Flashing code "003H" appears on the control panel's LED, indicating that the unit is ready to be programmed.

2. Set operating hours for the sanitation system:

With the minimum preset hours (code "003H") flashing, press the sanitizer button to increase the time from 003H, 005H to 008H hours (see "LED CODE CHART" section). Pressing the button after the maximum number of hours (code "008H") will deactivate the sanitation function and the LED panel will display the spa water temperature. If you have selected too many hours keep pressing to repeat the cycle. Once the operating time is set, the display LED panel will stop flashing after 10 seconds and the sanitation system starts working. For first time use of the spa, set the operating hours to "008H". During the sanitation, the information displayed on the LED panel alternates between the spa water temperature and the remaining hours of sanitation.

After the cycle is completed the LED panel displays the water temperature. Test the water with the included test strips, and make sure the free chlorine level is between 3-5 ppm.

Note: DO NOT press any other buttons on the control panel, ensure the heater is off and attach the spa cover during the sanitizing process.

3. Readjust operating time if necessary:

During the sanitizing process, the operating hours can be re-adjusted if necessary. Press the sanitizer button, the LED code "003H" will flash. Repeat step 2.

4. Turn off the sanitation system manually if necessary:

During the sanitizing process, you can turn off the sanitation system manually. Simply press the ON/OFF button on the control panel. The sanitation system will stop and the sanitizer icon light will disappear.

5. Restart the sanitation system:

When the programmed cycle ends, the LED panel displays the water temperature, the unit will stop sanitizing and the sanitizer icon light disappears. To restart the sanitation system, following the above steps.

6. Test the SPA water regularly:

The free chlorine level in the SPA water may vary depending on the number of occupants, local water condition and sunlight intensity exposure (outdoor use). During the initial use of the spa, test the spa water at least 2 times per day with the included test strips to maintain the free

chlorine between 3-5 ppm. After the free chlorine level appears to be stabilized, test the SPA water every week to maintain optimal sanitizing level.

Warning

Always unplug this product from the electrical outlet before removing, cleaning, servicing or making any adjustment to the product.

Water Sanitation

The spa owner must regularly check and keep the spa water sanitized with scheduled maintenance (daily, if necessary). Adding sanitizer and other chemical will control bacteria and viruses present in the spa water. The maintenance of a proper water balance through appropriate use of sanitizers is the single most important factor in maximizing the life and appearance of the spa tub as well as ensuring clean, healthy and safe water. Proper technique is important for water testing and treating the spa water. See your pool/spa professional for chemical, sanitizer, test kits and testing procedures questions.

CATUTION: ALWAYS FOLLOW THE CHEMICAL MANUFACTURER'S DIRECTIONS, AND THE HEALTH AND HAZARD WARNINGS.

Do not add chemicals if the spa is occupied. This can cause skin or eye irritation. Concentrated chlorine solutions can damage the spa tub. In no event is Intex Recreation Corp., Intex Development Co. Ltd., their related companies, authorized agents and service centers, retailers or employees liable to the buyer or any other party for costs associated with the loss of spa water, chemicals or water damage.

Preferred Water Chemistry Reading			
	Minimum	Ideal	Maximum
Free Chlorine	3ppm	3-5ppm	5 ppm
pH	7.2	7.2 - 7.6	7.8
Total Alkalinity (TA)	100ppm	100-120ppm	120 ppm
Calcium Hardness (CaCO ₃)	150ppm	150-200ppm	200ppm
Saturation Index (SI)	-0.3	0	+0.3
Water Temperature	20°C / 68 °F	20-40°C / 68-104°F	40°C / 104°F

Free chlorine: is the chlorine residual present in the spa water.

Result if too low – Inadequate level of disinfection.

Result if too high – cause odor problem, skin & eye irritation, corroded metals and other

materials.

pH: a value that indicates how acidic or basic the spa water is.

Result if too low – Corroded metals, eye & skin irritation, and destruction of total alkalinity.

Result if too high – Scale formation, cloudy water, shorter filter/heater runs, eye & skin irritation, poor chlorine efficiency.

Total Alkalinity (TA): indicates the degree of the water's resistance to pH change. It determines the speed and ease of pH change, so always adjust total alkalinity before adjusting the pH level.

Result if too low – Corroded metals, eye & skin irritation. Low alkalinity will cause the pH to be unstable. Result if too high – Scale formation, cloudy water, shorter filter/heater runs, eye & skin irritation, high chlorine demand.

Calcium Hardness (CaCO₃): refers to the amount of calcium and magnesium dissolved in the water. Result if too low – Difficulty balancing water, corrosion of metal components, eye & skin irritation and water foaming.

Result if too high – Scale formation, cloudy water, eye & skin irritation, difficulty balancing water and filter/ heater inefficiency.

Saturation Index (SI): temperature, calcium hardness concentration, total alkalinity and pH represent the main factors influencing scale formation. The tendency of water to either form scale or corrode is indicated by the Saturation Index (SI):

$$SI = pH + TF + CF + AF - 12.1$$

*Where: TF = Temperature Factor; CF = Calcium Hardness Factor; AF = Total Alkalinity Factor

Water Temperature		TF	Calcium Hardness (ppm)	CF	Total Alkalinity (ppm)	AF
(°C)	(°F)					
8	46	0.2	75	1.5	50	1.7
12	54	0.3	100	1.6	75	1.9
16	61	0.4	150	1.8	100	2.0
19	66	0.5	200	1.9	150	2.2
24	75	0.6	250	2.0	200	2.3
29	84	0.7	300	2.1	300	2.5
34	93	0.8	400	2.2	400	2.6
40	104	0.9	500	2.3	--	--
--	--	--	1000	2.6	--	--

Test the water pH, Temperature, Calcium Hardness and Total Alkalinity levels. Use the equivalent Factors in the SI equation.

SI = 0, Balance

If SI > 0, Scaling or cloudy water condition.

If SI < 0, Corrosive to metals or eye & skin irritating condition.

The SI is considered satisfactory if the value is within -0.3 to +0.3 range. Zero being perfect.

SPA Water Adjustment

How to adjust the spa water chemistry when the levels are off the range. **CAUTION:**

Always follow the chemical manufacturer's directions, and the health and hazard warnings.

Total Alkalinity (TA) Adjustment

Remove the spa cover to aerate the water and use the included test strips to check the chemistry level. Ensure the chlorine level in the water is between 3-5 ppm first, as chlorine will affect the TA test result.

If the TA level (and not the pH) is higher than 120 ppm, to lower the TA level, you add muriatic acid (hydrochloric acid) or sodium bisulfate.

If the TA level is lower than 60 ppm, you add sodium bicarbonate.

For example (for 4 adults), if the TA level is 180 ppm, the desired decrease is 60 ppm, from below chart, you need to add 121 g (0.269 Lb) of sodium bisulfate or 96 ml (0.101 qt) of muriatic acid.

If the test strip color is between 180 ppm and 240 ppm, and close to 180 ppm, you can also add 121 g (0.269 Lb) of sodium bisulfate or 96 ml (0.101 qt) of muriatic acid.

If the reading is more than 240 ppm, you can add sodium bisulfate or muriatic acid to the water drop by drop until the test strip indicates a 240 ppm reading, then add 238 g (0.528 Lb) of sodium bisulfate or 192 ml (0.202 qt) of muriatic acid.

NOTE: After adjustment, retest the water after 24 hours and adjust again if necessary.

Lowering Total Alkalinity

Amount of Sodium Bisulfate to lower Total Alkalinity

Desired level	60 ppm	80 ppm	100 ppm	120 ppm	140 ppm
Volume:	121 g	161 g	202 g	238 g	283 g
795 L / 210 gal	0.269 Lb	0.358 Lb	0.448 Lb	0.528 Lb	0.627 Lb
Volume:	168 g	224 g	279 g	335 g	391 g
1098 L / 290 gal	0.368 Lb	0.492 Lb	0.614 Lb	0.737 Lb	0.860 Lb

Amount of Muriatic Acid to lower Total Alkalinity

Desired Level	60 ppm	80 ppm	100 ppm	120 ppm	140 ppm
Volume: 210	96 mL	128 mL	160 mL	192 mL	223 mL

gal / 795 L	0.101 qt	0.135 qt	0.169 qt	0.202 qt	0.234 qt
Volume: 290 gal / 1098 L	132 mL	176 mL	220 mL	264 mL	308 mL
	0.139 qt	0.185 qt	0.232 qt	0.278 qt	0.324 qt

Raising Total Alkalinity

Amount of Sodium Bicarbonate to raise Total Alkalinity

Desired Level	20 ppm	40 ppm	60 ppm	80 ppm
Volume: 210 gal / 795 L	27 g 0.059 lb	53 g 0.118lb	80 g 0.178 lb	107 g 0.237 lb
Volume: 290 gal / 1098 L	37 g 0.081 lb	74 g 0.162 lb	111 g 0.244 lb	148 g 0.326 lb

pH Adjustment

After the total alkalinity has been lowered to 120 ppm or raised to 80ppm and the pH is still high or low, you can adjust it using the following chart.

Lowering pH

Lowering pH Using Muriatic Acid

Volume		210 gal (795 L)		290 gal (1098 L)	
Total Alkalinity		120 ppm	80 ppm	120 ppm	80 ppm
From → To	8.4 → 7.2	26 ml	18 ml	36 ml	24 ml
		0.028 qt	0.018 qt	0.038 qt	0.025 qt
	7.8 → 7.2	18 ml	12 ml	22 ml	16 ml
		0.019 qt	0.013 qt	0.026 qt	0.017 qt

Lowering pH Using Sodium Bisulfate

Volume		210 gal (795 L)		290 gal (1098 L)	
Total Alkalinity		120 ppm	80 ppm	120 ppm	80 ppm
From → To	8.4 → 7.2	32 g	21 g	43 g	29 g
		0.071 lb	0.047 lb	0.095 lb	0.063 lb
	7.8 → 7.2	21 g	14 g	29 g	20 g
		0.047 lb	0.032 lb	0.064 lb	0.043 lb

Raising pH

Raising pH Using Sodium Bicarbonate

Volume		210 gal (795 L)		290 gal (1098 L)	
Total Alkalinity		120 ppm	80 ppm	120 ppm	80 ppm
From → To	6.8 → 7.2	243 g	163 g	335 g	224 g
		0.541 lb	0.361 lb	0.737 lb	0.491 lb

Calcium Hardness Adjustment

Use the included test strips to check the water hardness level and adjust it following below chart.

Lowering Calcium Hardness

If your household water supply is treated with a softener, mix the spa hard water with the soft water according to the water volume ratio chart to lower the calcium hardness:

Lowering Calcium Hardness Using Soft Water

Initial Level	1000 ppm	500 ppm	350 ppm	250 ppm
Desired Level:	Water Volume Ratio (Vhard water:Vsoft water)			
100 ppm	1:9	1:4	2:5	2:3

Raising Calcium Hardness

If the calcium hardness level in the spa water is lower than 100 ppm, add calcium chloride into the spa water.

Volume	210 gal (795 L)		290 gal (1098 L)	
m (CaCl ₂)	0.197 Lb	89 g	0.269 Lb	122 g

WARNING

Muriatic acid is a caustic chemical and liquid solution of sodium bisulfate (NaHSO₄) is highly acidic. Handle all chemicals with care and wear extra personnel protective equipment including goggle and gloves. It is very important not to splash acid onto your skin or clothing, or into your eyes.

Maintenance of Spa Water and Cartridge

Protect all the spa occupants from possible water-related illnesses by keeping the spa water clean and sanitized. Always practice good hygiene.

To ensure proper spa water quality follow these procedures:

1. Inspect and clean the filter cartridge once a week, and change the filter cartridge as needed.
 - a. Unscrew the cartridge housing assembly from the spa tub wall and remove the cartridge (**see drawing 11**).
 - b. Use a garden hose to rinse off the cartridge. If the cartridge remains soiled and discolored it should be replaced. Keep spare cartridges on hand.
 - c. Reinstall the clean cartridge back into the cartridge housing and replace the

cartridge housing assembly back onto the spa tub wall

2. Change the spa water every 2~3 months, or it becomes cloudy and proper water chemistry does not clear it up. See “Spa Tub Drainage” and “Spa Tub Cleaning” sections for details.
3. Use spa chemicals to maintain proper water chemistry. Spa damage resulting from misuse of chemicals and mismanagement of spa water is not covered by the warranty.
4. All occupants must shower before entering the spa.

Unplug the power cord before cleaning the system. Cover the water inlet and outlet with the plugs to prevent water spillage. After completing all maintenance tasks, you must plug the power cord back in and remove the plugs.

Electrolytic Cell Cleaning

The electrolytic cell has a self cleaning function incorporated into the electronic control's programming. In most cases this self cleaning action will keep the cell working at optimum efficiency. In some regions, the SPA water is hard (high mineral content) which varies depending on the local water condition, this would cause deposits on the titanium plate and affect the sanitizing efficiency, so the cell may require periodic manual cleaning. To maintain maximum performance, we recommend that you open and visually inspect the electrolytic cell every two weeks for SPA water (Calcium hardness < 100 ppm) or weekly for SPA water (Calcium hardness > 350 ppm).

The following steps provide instructions on how to clean the cell.

Inspection and cleaning:

1. Turn off the spa and unplug the power cord from the electrical socket.
2. Unscrew the filter cartridge assembly from the spa stub wall, and use the included plugs **(15 & 23)** to cover the water inlet and outlet fittings from inside of the spa tub to prevent water from flowing out.
3. Remove the four screws from the transparent cover using a Phillips screwdriver (not included) and remove the cover from the spa control unit.
4. Unplug the electrolytic cell cord. Unscrew the electrolytic cell nut in a counter-clockwise motion using the included electrolytic cell nut wrench **(20)**.
5. Pull out the electrolytic cell and place it in a container, pour kitchen grade vinegar into the container to soak the titanium plate for about one hour until no deposits remain.
6. Remove the electrolytic cell and flush the titanium plate with fresh water. Be careful: Keep the electrolytic cell receptacle completely dry, do not let it

come into contact with the vinegar and water.

7. Reverse the above steps to reinstall the electrolytic cell.

NOTE: Ensure the notch on the electrolytic cell is aligned with the ridge on the electrolytic cell housing.

The Test Strips can test the “Free Chlorine”, “pH”, “Total Alkalinity” and “Calcium Hardness” levels at the same time. We recommend that you test the water chemistry weekly, and maintain the chlorine concentration at 3-5 ppm.

Directions and Use

1. Dip the entire strip into the water and remove immediately.
2. Hold the strip level for 15 seconds. Do not shake excess water from the strip.
3. Now compare the strip pad to the color chart on the packaging label. If necessary, adjust the chemical level in the spa water. It is very important, to use the proper technique when testing the water's chemical level. Read and follow the written strip instructions carefully.

The life expectancy of the electrode is 2000 hours under normal conditions.

Spa Tub Drainage

1. Turn off and unplug the spa control unit.
2. Connect the drain valve adaptor to a garden hose and point the other end of the garden hose to a suitable draining area (**see drawing 12**).
3. Remove the drain valve cap from outside of the spa tub and attach the drain valve adaptor to the drain valve (**see drawing 12**).
4. From inside of the spa tub, open the drain valve cap, water will start flowing out from the garden hose.
5. When the water stops draining, disconnect the spa control unit from the spa tub wall. Lift the spa tub wall from the side opposite the drain, leading any remaining water to the drain and emptying the spa completely (**see drawing 13**).
6. Turn over the spa tub to empty any remaining water (**see drawing 14**).
7. Unscrew the drain valve on the spa control unit side using a coin to drain out any water (**see drawing 15**).
8. Use a clean towel to wipe up any remaining water and moisture on the spa tub and spa control unit.
9. Ensure the spa tub and spa control unit are thoroughly dried.
NOTE: The enclosed plugs (**15 & 23**) can be used to cover the water inlet and outlet connectors from the inside of the spa tub to prevent water from flowing out.

Spa Tub Cleaning

If dirt is visible in the water or water becomes cloudy and proper water chemistry does not clear it up, change the water and clean the spa tub. See “Spa Tub Drainage” section on how to drain the spa.

While empty, remove the cartridge housing from inside of the spa tub wall, clean and/or replace the filter cartridge. Use a sponge and mild soap solution to wipe away any soil or stains on the inside of the spa wall. Rinse thoroughly before refilling with clean water.

IMPORTANT: Do not use steel wool, hard brushes or abrasive cleaners.

Spa Tub Air Valve Fastening

Check the spa tub air valve for leakage and tightness before use. If air is leaking from the air valve, use the provided wrench (22) to tighten the air valve as follow:

1. Make sure the spa tub is deflated, open the air valve cap and insert the wrench (22) into the air valve body (see drawing 16).
2. With one hand, hold the backside of the air valve base from the inside of the spa tub wall and turn the wrench (22) clockwise.

IMPORTANT: Never adjust the air valve base when the spa is in use or filled with water. Only use the air valve wrench if the air valve is loose or there is leakage around air valve base. Do not over tighten the air valve: over tightening can damage the valve. Just ensure the air valve is snug and not leaking.

Spa Cover

The attachment buckles of the cover are locking buckles. Two keys are provided in the plastic bag with the manual and other accessories. Each buckle is marked with "locked" and "unlocked" symbols for easy operation: put the key into the slot on the buckle and turn it to the appropriate position to lock or unlock the buckle respectively.

To assure safety from unauthorized access, always put the cover on when spa is not in use and lock all buckles. Always keep the keys out of reach of children. In case you misplace the keys, you can use any similar size flat screwdriver to lock or unlock the buckles.

Inspect the spa cover regularly for leaks, premature wear and tear, damage, or signs of deterioration. Never use a worn or damaged cover: it will not provide the level of protection required to prevent unsupervised access to the spa by a child.

Spa Tub and Cover Air Bladder Repair

Use the enclosed repair patch to repair any puncture:

- Clean and dry the area to be repaired thoroughly.
- Remove the patch backing paper and press patch firmly over the puncture.
Smooth out the surface to remove any air bubbles under the patch.

IMPORTANT

The ambient temperatures of air have an effect on the spa tub internal pressure. Air inside of the spa tub may expand and contract with varying temperature leading to reduce pressure inside of the spa tub. If this occurs, simply use the provided pressure gauge to check the internal air pressure and add more air if necessary.

STORAGE

1. Drain and clean the spa following the “Spa Tub Drainage” and “Spa Tub Cleaning” sections.
2. Reverse set up instructions to deflate and disassemble the spa tub, spa control unit and spa cover air bladder.
3. To deflate the tub and the cover air bladder:
 - a) Open the deflation outlet cap **(35)** with the included bolt wrench **(6)** (see drawing **17**).
 - b) Insert deflation hose adaptor **(36)** into the deflation outlet.
 - c) Insert inflation hose **(7)** over the deflation hose adaptor **(36)**.
 - d) Insert the other end of the inflation hose into the tub air valve or cover air bladder valve.
 - e) Press the air bubble button to deflate.
 - f) When deflation is completed reverse above steps and ensures the deflation outlet cap **(35)** is securely fastened.

Caution: Only use for the purpose described in this manual.
Keep the inflation hose away from water or small objects when the deflation function is activated to avoid damage to the blower motor.
4. Make sure all the spa components and accessories are thoroughly clean and dry before storage. Air-dry the spa tub in the sun for an hour before folding.
5. Fold the spa tub loosely and avoid any sharp corners to prevent damage or leakage to the spa tub liner.
6. Prepare additional new cartridges for next time use.
7. Store the spa tub and accessories in a dry, temperature controlled, between 0° – 40°C (32° – 104 °F), storage location.
8. The original packing can be used for storage.

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
NO DISPLAY/SPA CONTROL UNIT DOES NOT WORK	<ul style="list-style-type: none"> - Spa is unplugged or off. - Control panel cable plus loose. - Power Failure. - GFCI/RCD tripped. - GFCI/RCD broke. 	<ul style="list-style-type: none"> - Ensure the spa is plugged and switched on. - Ensure the control panel cable plug is firmly attached to the control base receptacle. - Check the power source. - Reset the GFCI/RCD. - Contact Intex Service Center.
HOUSEHOLD CIRCUIT BREAKER TRIPPED	<ul style="list-style-type: none"> - Circuit breaker under rated. - Overloaded circuit breaker. - An electrical fault in the line. 	<ul style="list-style-type: none"> - Ensure correct circuit breaker rating. - Provide a dedicated circuit breaker feeding the spa electrical outlet only. - Contact a qualify electrician to correct the electrical fault.
NOT HEATING PROPERLY	<ul style="list-style-type: none"> - Temperature set too low. - Dirty filter cartridge. - Water temperature decreasing during heater STANDBY mode. - Heating element failed. 	<ul style="list-style-type: none"> - Increase the temperature and attach the spa cover. - Clean or replace the filter cartridge in time. - If heater is in STANDBY mode, press the flame button twice to heat up the water to the set temperature. - Contact Intex Service Center.

JET FUNCTION DOES NOT WORK	<ul style="list-style-type: none"> - Jet pump is too hot. 	<ul style="list-style-type: none"> - Turn off and unplug the spa. Let it cool down and restart all over again. - If problem persists contact Intex Service Center.
JET OUTPUT IS WEAK	<ul style="list-style-type: none"> - Low water level. - Obstruction in the suction inlet inside the tub. - Jet nozzles clogged or dirty. - Jet nozzles plumbing pipes damaged. 	<ul style="list-style-type: none"> - Add water between MIN and MAX level. - Ensure suction inlet is not covered or blocked. - Clean any dirt inside jet nozzles. - Contact Intex Service Center.
JET AIR CONTROL KNOW NOT WORKING	<ul style="list-style-type: none"> - Jet nozzles clogged or dirty. - Control panel jet airflow hose loose or damaged. 	<ul style="list-style-type: none"> - Clean any dirt inside the jet nozzles. - Ensure the jet air hose in the control panel (3) is not damaged and securely attached. Replace if needed. - Contact Intex Service Center.
FILTRATION PUMP NOT WORKING	<ul style="list-style-type: none"> - Dirty filter cartridge. - Filtration inlet and/or outlet clogged. - Filter pump motor failed. 	<ul style="list-style-type: none"> - Clean or replace the filter cartridge in time. - Check and clean filtration inlet and outlet regularly. - Contact Intex Service Center.
WATER NOT CLEAN	<ul style="list-style-type: none"> - Cartridge assembly not properly attached. - Insufficient filtering time. - Dirty filter cartridge. - Improper water maintenance. - Filtration inlet and outlet clogged. 	<ul style="list-style-type: none"> - Ensure the cartridge assembly is properly attached. - Increase filtration time. - Clean or replace the filter cartridge in time. - Keep the spa water properly sanitized. Refer to the chemical manufacturer's instructions. - Check and clean filtration inlet and outlet regularly.
PUMP CONNECTORS ARE NOT LEVEL WITH THE SPA CONNECTORS	<ul style="list-style-type: none"> - One characteristic or PVC is that it changes shape, which is normal. 	<ul style="list-style-type: none"> - Elevate the pump with wood or another type of insulated material to bring the pump's connectors level with the spa's connectors.
TUB HAS A STRANGE SHAPE	<ul style="list-style-type: none"> - Expanded internal air pressure by strong sunshine. 	<ul style="list-style-type: none"> - Do not expose the product under direct sunshine. - Check the air pressure and release air if necessary. During very hot weather, you must check to see whether it is necessary to release some air. This is to avoid any possible damage to the tub.
TUB LOSES AIR PRESSURE	<ul style="list-style-type: none"> - Air valve cap loose. - Air valve base loose. - Hole, cut or split on spa tub. 	<ul style="list-style-type: none"> - Ensure air valve cap is securely closed. - Fill up the spa tub with air then make sure the air valve base is tighten, see "Spa Tub Air Valve Fastening" section. - Put liquid soap and water in a squirt bottle and spray on seams. If there is a leak it will bubble. After you find the leak, clean and dry the leaking area, then apply the repair patch that comes with your spa.
LEAKING BETWEEN SPA TUB CONNECTORS	<ul style="list-style-type: none"> - Spa control base inlet/outlet connections not securely tight. - Spa control base inlet/outlet o-ring missing/dirty. 	<ul style="list-style-type: none"> - Tighten the inlet and outlet connections. - Coat the o-ring with petroleum jelly for water proof. - Remove grid from inside spa with a screwdriver, ensure inlet/outlet

AND CONTROL UNIT CONNECTORS		o-ring is in place, clean and not damaged.
SPA IS TOO NOISY IN FILTRATION MODE ONLY	<ul style="list-style-type: none"> - Control base components not securely attached. - Control base ground not level and firm. - Spa filter motor failed. 	<ul style="list-style-type: none"> - Ensure control panel, back cover and all inlet/outlet are securely connected. - Ensure ground is level, firm and smooth. - Replace the failed filter motor with a new one.
INSUFFICIENT CHLORINE	<ul style="list-style-type: none"> - Insufficient operating time of the sanitation system and/or heater is running at the same time. - Chlorine loss due to intense sunlight exposure. - The bather load had increased. - Clogged or dirty electrolyte cell. 	<ul style="list-style-type: none"> - Increase the sanitation system operating time and ensure the heater is off during the sanitation process. See "Sanitation System Operating Instructions". - Use a SPA cover when the SPA is not in use and/or when the sanitation system is operating. - Increase the sanitation system operating time and test the water using the test strips. See "Sanitation System Operating Instructions". - Check and clean the cell if necessary. See "Maintenance".
BUBBLE AIR BLOWER DOES NOT WORK	<ul style="list-style-type: none"> - Air blower pump is too hot. 	<ul style="list-style-type: none"> - Turn off and unplug the spa. Let it cool down and restart all over again. - If problem persists contact Intex Service Center.
LED Panel Code Flash & Alarm On (NOTE: Always turn off the power before cleaning and servicing.)		
E90	<ul style="list-style-type: none"> - No water flow. 	<ul style="list-style-type: none"> - Turn off and unplug the control unit. - Ensure the outlet cover grid is clean and free from obstructions. - Clean or replace the cartridge, see Maintenance and Storage section. - Ensure the in/outlet connections on the spa tub and filter pump are not blocked. - Keep the spa water properly sanitized to ensure a clean and unclogged filter cartridge. - Press the button to turn off the unit. Release trapped air by unscrewing the drain valve cap on the control base side with a coin. Air has been release once a steady stream of water is glowing out from the drain valve. Wait for 15 seconds and screw the drain valve cap back. Press the button to activate the control panel buttons, and then run the filter function by pressing the button to push out any remaining air in the system. - Turn off and unplug the control unit. Plug the GFCI/RCD and restart all over again. - If problem persists, contact Intex Service Center.
E91	<ul style="list-style-type: none"> - Dirt or scale on titanium plates. - Low salt level / no salt. - Electrolyte cell cord is loose. - Possible electrolytic cell 	<ul style="list-style-type: none"> - Remove electrolytic cell for inspection. Clean it if necessary. See "Maintenance". - Add salt. See "Salt Level Information". - Ensure that the cell cord is plugged

	failure.	<ul style="list-style-type: none"> - firmly into the cell receptacle. Contact Intex Service Center. Replace the cell if needed.
E92	<ul style="list-style-type: none"> - High salt level. 	<ul style="list-style-type: none"> - Partially drain the pool and refill it with fresh water. See "Salt Level Information".
E94	<ul style="list-style-type: none"> - Water temperature too low. 	<ul style="list-style-type: none"> - If the ambient temperature is below 4°C (39°F), we recommend not to use the spa. - Turn off and unplug the control unit. Plug the GFCI/RCD and restart all over again. - Turn off and unplug the control unit, add some warm water to raise the spa water temperature above 5°C (41°F), then press the button to heat up the water to the desired temperature. - If problem persists, contact Intex Service Center.
E95	<ul style="list-style-type: none"> - Water temperature too high. 	<ul style="list-style-type: none"> - Turn off and unplug the control unit. Where the water has cooled down, plug the GFCI/RCD and restart all over again. - Turn the heater off, then press the filter and jet buttons to lower the water temperature. - If problem persists, contact Intex Service Center.
E96	<ul style="list-style-type: none"> - System Error. 	<ul style="list-style-type: none"> - Turn off and unplug the control unit, use the cap to stop the water from flowing out of the tub, disassemble and drain out the control unit. Reassemble the control unit back to the tub. Plug the GFCI/RCD and restart all over again. - If problem persists, contact Intex Service Center.
E99	<ul style="list-style-type: none"> - Water temperature sensor broken. 	<ul style="list-style-type: none"> - Contact Intex Service Center.
END	<ul style="list-style-type: none"> - After 72 hours of continuous heating operation, the pump will hibernate automatically. The rapid heating and water filtration functions are disabled. 	<ul style="list-style-type: none"> - Press the button to re-activate the filter pump.

WARRANTY

Your PureSpa has been manufactured using the highest quality materials and workmanship. All Intex products have been inspected and found free of defects prior to leaving the factory. The Limited Warranty applies only to the PureSpa listed below.

The provisions of this Limited Warranty apply only to the original purchaser and is not transferable. This Limited Warranty is valid for the period noted below from the date of the initial retail purchase. Keep your original sales receipt with this manual, as proof of purchase will be required and must accompany warranty claims or the Limited Warranty is invalid.

PureSpa Warranty – 1 Year

If a manufacturing defect is found within the periods noted above, please contact the appropriate Intex Service Center listed in the separate "Authorized Service Centers" sheet. The Service Center will determine the validity of the claim. If the Service Center directs you to return the product, please carefully package the product and send with shipping and insurance prepaid to the Service Center. Upon receipt of the returned product, the Intex Service Center will inspect the item and determine the validity of the claim. If the provisions of this warranty cover the item, the item will be repaired or replaced at no charge.

Any and all disputes regarding the provisions of this Limited Warranty shall be brought before an informal dispute settlement board and unless and until the provisions of these paragraphs are carried forth, no civil action may be instituted. The methods and procedures of this settlement board shall be subject to the rules and regulations set forth by the Federal Trade Commission (F.T.C.). IMPLIED WARRANTIES ARE LIMITED TO THE TERMS OF THIS WARRANTY AND IN NO EVENT SHALL INTEX, THEIR AUTHORIZED AGENTS OR EMPLOYEES BE LIABLE TO THE BUYER OR ANY OTHER PARTY FOR DIRECT OR CONSEQUENTIAL DAMAGES OR LIABILITIES. Some states or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

The Limited Warranty does not apply if the products are subject to negligence, abnormal use or operation, accident, improper operation, improper voltage or current contrary to operating instructions, or to damage by circumstances beyond Intex's control, including but not limited to, ordinary wear and tear and damage caused by exposure to fire, flood, freezing, rain, or other external environmental forces. This Limited Warranty applies only to those parts and components sold by Intex. The Limited Warranty does not cover unauthorized alterations, repairs or disassembly by anything other than Intex Service Center personnel.

DO NOT GO BACK TO THE PLACE OF PURCHASE FOR RETURN OR REPLACEMENT. IF YOU ARE MISSING PARTS OR NEED ASSISTANCE, PLEASE CALL US TOLL-FREE (FOR U.S. AND CANADIAN RESIDENTS): 1-800-234-6839 OR VISIT OUR WEBSITE: WWW.INTEXSTORE.COM.

Proof of Purchase must accompany all returns or the warranty claim will be invalid.

SAVE THESE INSTRUCTIONS