

2000.02.08

ECLIPS I
COMMERCIAL
3133
DETERGENT
DISINFECTANT

For hospitals,
institutional and industrial use

READ THE LABEL BEFORE USING

DIN 02067250

WARNING

POISON

CORROSIVE

GUARANTEE

Alkyl (40% C12, 50% C14, 10% C16)	
dimethyl benzyl ammonium chloride	4,340%
Octyl decyl dimethyl ammonium chloride	3,255%
Didecyl dimethyl ammonium chloride	1,953%
Dioctyl dimethyl ammonium chloride	1,302%

REGISTRATION NO. 23709

PEST CONTROL PRODUCTS ACT

CHOISY LABORATORIES LTD.
Louiseville, Québec, Canada J5V 2L7

NET CONTENTS:

LOT NO:

ECLIPS I is a proven "one-step" disinfectant, sanitizer, fungicide, virucide and mildewstat, which is effective in water up to 400 ppm hardness in the presence of 5% blood serum. Can be

used on walls, floors and all other hard non-porous surfaces.

DIRECTIONS FOR USE

APPLICATION: Apply ECLIPS I on surfaces with a cloth, or a mop in order to wet the surface thoroughly. For heavily soiled areas, a preliminary cleaning is required. Prepare a fresh solution daily or when use solution becomes visibly dirty.

DISINFECTION; MOLD AND MILDEW CONTROL, TO DISINFECT HARD, NON-POROUS SURFACES: Add 8 mL of ECLIPS I per litre (1 1/4 oz per gallon) of water. Treated surfaces must remain wet for 10 minutes. At this use level, ECLIPS I is also virucidal and fungicidal.

SANITIZING: non-porous, non-food contact surfaces - Add 1.5 mL of ECLIPS I per litre (1/4 oz per gallon) of water. Treated surfaces must remain wet for 1 minute.

INSTRUCTIONS FOR CLEANING AND DECONTAMINATING AGAINST HIV-1 ON SURFACES AND OBJECTS SOILED WITH BLOOD OR BODILY FLUIDS - ECLIPS I is effective against HIV-1 (Human Immunodeficiency Virus) in hard matter (5% blood serum). When handling items soiled with blood or bodily fluids, wear disposable latex gloves, mask and eye coverings. Thoroughly clean blood or bodily fluids from surfaces before applying ECLIPS I. Then add 8 mL of ECLIPS I per litre (1 1/4 oz per gallon) of water. Allow surface to remain wet for 10 minutes. **DISPOSAL OF INFECTIOUS MATERIALS:** blood and other bodily fluids should be disposed of according to provincial and federal regulations for infectious waste disposal.

PRECAUTIONS: KEEP OUT OF REACH OF CHILDREN. Corrosive to eyes and skin. Do not get in eyes, on skin or on clothing. Harmful if swallowed. Avoid contamination of food. All surfaces subject to food contact must be thoroughly rinsed with potable water after use of this product.

FIRST AID: In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes and call a physician. Remove and wash contaminated clothing before reuse. If swallowed, drink promptly a large quantity of milk, egg whites, gelatin solution or if these are not available, drink large quantities of water. Never give anything by mouth to an unconscious person. Call physician immediately.

TOXICOLOGICAL INFORMATION: Probable mucosal damage may contraindicate the use of gastric lavage. Measures against circulatory shock, respiratory depression and convulsion may be needed.

DISPOSAL:

1. Rinse the emptied container thoroughly and add the rinsings to treatment site.
2. Follow provincial instructions for any required additional cleaning of the container prior to its disposal or reconditioning.
3. Dispose of container in accordance with provincial requirements.
4. For information on the disposal of unused, unwanted product and the cleanup of spills, contact the regional office of Environment Canada.
5. For small spills, Recover free liquid. Soak up residue with solids absorbent. DO NOT FLUSH INTO SURFACE STREAMS. INFORM ENVIRONMENT CANADA AS IN NO. 4.

NOTICE TO USER: This control product is to be used only in accordance with the directions on this label. It is an offence under the Pest Control Products Act to use a product under unsafe conditions.

Made in Canada

This label transcript service is offered by the Pest Management Regulatory Agency to provide efficient searching for label information. This service and this information do not replace the official hard-copy label. The PMRA does not provide any guarantee or assurance that the information obtained through this service is accurate, current or correct, and is therefore not liable for any loss resulting, directly or indirectly, from reliance upon this service.

+))