

96.05.01

LONZA FORMULATION
DC-108N

Disinfectant-Cleaner-Sanitizer-Fungicide-Mildewstat-
Virucide-Deodorizer for Hospitals,
Institutional and Industrial Use

Effective in hard water up to 400 ppm hardness (calculated as
CaCO₃) in the presence of 5% serum contamination

GUARANTEE:

Didecyl dimethyl ammonium chloride 15.36%

COMMERCIAL

DANGER POISON

CORROSIVE TO EYES

SKIN IRRITANT

READ THE LABEL BEFORE USING

REGISTRATION NO. 24294

PEST CONTROL PRODUCTS ACT

DIN 02016907

NET CONTENTS:

Manufactured by
LONZA INC.
17-17 Route 208,
Fair Lawn, N.J.
07410

Canadian Agent:
CANADA COLORS & CHEMICALS
80 Scarsdale Road
Don Mills, Ontario
M3B 2R7

Lot No Expiry Date

30NOV95

Description

Cross-contamination is of major housekeeping concern not only in hospitals, but in food processing establishments.

LONZA FORMULATION DC-108N has been formulated to aid in the reduction of cross-contamination in these areas.

LONZA FORMULATION DC-108N is a concentrated one-step disinfectant cleaner that is effective against a broad spectrum of bacteria, is virucidal, fungicidal, and inhibits the growth of mold and mildew and their odours when used as directed.

LONZA FORMULATION DC-108N is an effective one-step sanitizer-cleaner for use on non-food contact surfaces. When used as directed, LONZA FORMULATION DC-108N will deodorize surfaces in toilet areas, behind and under sinks and counters, garbage cans and garbage storage areas, and other places where bacterial growth can cause mal odours.

LONZA FORMULATION DC-108N is recommended for use in hospitals, medical and dental offices, nursing homes, food processing plants, food storage areas and kitchens. This product contains no phosphorous.

Industrial/Institutional/Janitorial

LONZA FORMULATION DC-108N is a no-rinse neutral pH disinfectant cleaner that disinfects, cleans, and deodorizes in one labour-saving step.

LONZA FORMULATION DC-108N is an economical concentrate that can be used with a mop and bucket, trigger sprayer, sponge, or by soaking. Provides effective cleaning strength that will not dull most metal-interlock floor finishes, and does not require a rinse prior to recoat. Maximizes labour results by effectively controlling odours for a long lasting clean.

LONZA FORMULATION DC-108N is a hospital disinfectant, bactericidal at 1:256 dilution (4 ml per litre) according to the current AOAC Use-Dilution Test method, modified in the presence of 400 ppm synthetic hard water (calculated as CaCO₃) plus 5% organic serum against:

Pseudomonas aeruginosa
Staphylococcus aureus
Salmonella choleraesuis
Brevibacterium ammoniagenes
Chlamydia psittaci
Escherichia coli
Enterobacter aerogenes
Enterobacter cloacae
Klebsiella pneumoniae
Proteus vulgaris

Salmonella typhi
Salmonella typhimurium
Salmonella schottmuelleri
Serratia marcescens
Shigella flexneri,
Shigella sonnei
Streptococcus faecalis
Streptococcus pyogenes
Shigella dysenteriae
Staphylococcus epidermidis

Methicillin Resistant Microorganisms:

Staphylococcus aureus
Escherichia coli
Klebsiella pneumoniae
Streptococcus faecalis
Pseudomonas cepacia

LONZA FORMULATION DC-108N is virucidal at 1:256 dilution (4 mL per litre) according to the virucidal qualification, modified in the presence of 400 ppm hard water plus 5% organic serum against: Influenza A, Herpes Simplex Type 1, Herpes Simplex Type 2, Vaccinia, Rubella.

LONZA FORMULATION DC-108N is fungicidal at 1:256 dilution (4 mL per litre) according to the AOAC fungicidal test, modified in the presence of 400 ppm hard water plus 5% organic serum against: Trichophyton mentagrophytes (the athlete's foot fungus), Candida albicans and Aspergillus niger.

LONZA FORMULATION DC-108N is a sanitizer for hard non-porous non-food contact surfaces at 4 mL per litre dilution against: Staphylococcus aureus and Enterobacter aerogenes.

Food Processing Operations:

For use in federally inspected meat and poultry plants as a general cleaning agent on all surfaces, or for use with mechanical cleaning devices in all departments. Before use of this compound, food products and packaging materials must be removed from the room or carefully protected. After use of this compound, all surfaces in the areas must be thoroughly rinsed with potable water.

General Use Directions:

Apply LONZA FORMULATION DC-108N to walls, floors and other hard (inanimate) non-porous surfaces (such as metal, stainless steel, porcelain, and plastic), thoroughly wetting surfaces as recommended and required. LONZA FORMULATION DC-108N can be applied with a cloth, mop, sponge, spray or soaked. For heavily soiled areas, a preliminary cleaning is required. For sprayer applications, use a coarse spray device. Spray 15-20 cm from

surface, rub with brush, sponge or cloth. Do not breathe spray mist.

Disinfection Directions: Add 4 mL per litre of water, to disinfect hard, non-porous surfaces. Treated surfaces must remain wet for 10 minutes. Prepare a fresh solution daily or when use-solution becomes visibly dirty.

Virucidal Directions: Add 4 mL per litre of water, for disinfection against all viruses claimed. Treated surfaces must remain wet for 10 minutes. Prepare a fresh solution daily or when use-solution becomes visibly dirty.

Mold and Mildew Control: Add 4 mL per litre of water, to control the growth of mold and mildew and their odours on hard, non-porous surfaces. Thoroughly wet all treated surfaces completely. Let air dry. Repeat application weekly or when growth or odours reappear.

Sanitizing Non-Food Contact Surfaces: Add 4 mL per 8 litres of water, to sanitize hard non-porous environmental surfaces. Treated surfaces must remain wet for 60 seconds.

Non-Acid Bowl Disinfection/Cleaner From Concentrate: Add 4 mL to the toilet bowl and mix. Brush thoroughly over exposed surfaces and under the rim, allow to stand for 10 minutes and flush. From Use-Solution: Empty toilet bowl or urinal and apply 4 mL/L use-solution to exposed surfaces including under the rim with a cloth, mop, sponge or sprayer.

Instructions for Cleaning and Decontaminating Against HIV-1 on Surfaces and Objects Soiled with Blood or Bodily Fluids: This product is effective against HIV-1 (Human Immunodeficiency Virus) in hard water up to 400 ppm (CaCO₃), and in the presence of organic soil (5% blood serum).

Personal Protection: Clean-up should always be done wearing protective latex gloves, gowns, masks and eye protection

Cleaning Procedure: Thoroughly clean blood or bodily fluids from surfaces before applying "LONZA [FORMULATION DC-108N".

Contact Time: To kill HIV-1, apply "LONZA FORMULATION DC-108N" at 4 mL per litre of water and allow surface to remain wet for 10 minutes.

Disposal of Infectious Materials: Blood, body fluids, cleaning materials and clothing should be autoclaved and disposed of according to provincial and local regulations for infectious waste disposal.

FIRST AID INSTRUCTIONS: In case of contact, immediately flush eyes or skin with plenty of water for at least 15 minutes. For eyes, contact a physician. Remove and wash all contaminated

clothing, wash them separately from household laundry before reuse. If swallowed, drink milk, egg whites, gelatin solution or if none of these are available, drink large quantities of water. Call a physician immediately.

PRECAUTION: KEEP OUT OF REACH OF CHILDREN. FATAL/POISONOUS IF SWALLOWED, INHALED OR ABSORBED THROUGH SKIN. CORROSIVE. CAUSES EYE AND SKIN DAMAGE. DO NOT GET IN EYES, ON SKIN OR CLOTHING. DO NOT INHALE VAPOURS. Wear full-face protection (goggles/faceshield), coveralls, chemical resistant gauntlet gloves, apron, chemical resistant boots and respirator when handling the concentrate or during mixing. Wash hands and face before eating, drinking, smoking, or using the toilet. Avoid contamination of food Do not store in food processing areas or food storage areas. When handling diluted product wear impermeable gloves.

NOTICE TO USER: This control product is to be used only in accordance with the directions on this label. It is an offense under the Pest Control Products Act to use a control product under unsafe conditions.

TOXICOLOGICAL INFORMATION: Probable mucosal damage may contraindicate the use of gastric lavage. Measures against circulatory shock, respiratory depression and convulsion may be needed. CONTAINS: Surfactant, sequestrant, fragrance and dye.

DISPOSAL:

1. Rinse the emptied container thoroughly and add the rinsings to the treatment site.
2. Follow provincial instructions for any required additional cleaning of the container prior to disposal.
3. Make the empty container unsuitable for further use.
4. Dispose of the container in accordance with provincial requirements.
5. For information on the disposal of unused, unwanted product and the cleanup of spills, contact the Provincial Regulatory Agency or the Manufacturer.

This label transcript service is offered by the Pest Management Regulatory Agency to provide efficient searching for label information. This service and this information do not replace the official hard-copy label. The PMRA does not provide any guarantee or assurance that the information obtained through this service is accurate, current or correct, and is therefore not liable for any loss resulting, directly or indirectly, from reliance upon this service.

