

LABEL

CLEARWATER SALT CHLORINATOR
CHLORINE GENERATING DEVICE
MODEL LM2-24 FOR RESIDENTIAL POOLS
DOMESTIC
REGISTRATION NUMBER 27580
PEST CONTROL PRODUCTS ACT

READ THE LABEL, INSTALLATION AND INSTRUCTION MANUALS BEFORE USING.

PLEASE KEEP YOUR OPERATION MANUAL AS IT CONTAINS YOUR WARRANTY.

THE CLEARWATER SALT CHLORINATOR CONTAINS A POWER PACK AND A CELL.

Controls Bacteria and Algae in Swimming Pool Waters.

Maximum output of hypochlorous acid equivalent to 0.426 kg of free available chlorine per day.

One Clearwater Salt Chlorinator Model LM2-24 can treat a maximum of 130,000 Litres of swimming pool water.

For swimming pools, a minimum of 1 ppm of free available chlorine must be maintained.

WARNING: Operating Clearwater Salt Chlorinator Model LM2-24 without water flow through the cell can cause a build up of flammable gases which can result in FIRE OR EXPLOSION.

KEEP OUT OF REACH OF CHILDREN

ZODIAC POOL CARE CANADA
2115 SOUTH SERVICE RD. W. #3
OAKVILLE, ONTARIO
L6L 5W2
CANADA

REPLACEMENT CELL LABEL

CLEARWATER LM2-24 REPLACEMENT CELL

ZODIAC POOL CARE CANADA
2115 SOUTH SERVICE RD. W. #3
OAKVILLE, ONTARIO
L6L 5W2
CANADA

Replacement cell for the chlorine generating device Clearwater Salt Chlorinator Model LM2-24
REGISTRATION NUMBER 27580, PEST CONTROL PRODUCTS ACT. This cell must only
be used on this model of chlorine generating device.

Read the Label, the Installation Manual and Operation Manual of the chlorine generating device
Clearwater Salt Chlorinator Model LM2-24 before using.

OPERATION MANUAL

CLEARWATER SALT CHLORINATOR
CHLORINE GENERATING DEVICE
MODEL LM2-24 FOR RESIDENTIAL POOLS
DOMESTIC
REGISTRATION NUMBER 27580
PEST CONTROL PRODUCTS ACT

READ THE LABEL, INSTALLATION AND INSTRUCTION MANUALS BEFORE USING.

PLEASE KEEP YOUR OPERATION MANUAL AS IT CONTAINS YOUR WARRANTY.

THE CLEARWATER SALT CHLORINATOR CONTAINS A POWER PACK AND A CELL.

Controls Bacteria and Algae in Swimming Pool Waters.

Maximum output of hypochlorous acid equivalent to 0.426 kg of free available chlorine per day.

One Clearwater Salt Chlorinator Model LM2-24 can treat a maximum of 130,000 Litres of swimming pool water.

For swimming pools, a minimum of 1 ppm of free available chlorine must be maintained.

WARNING: Operating Clearwater Salt Chlorinator Model LM2-24 without water flow through the cell can cause a build up of flammable gases which can result in FIRE OR EXPLOSION.

KEEP OUT OF REACH OF CHILDREN.

Retain this manual for future reference.

ZODIAC POOL CARE CANADA
2115 SOUTH SERVICE RD. W. #3
OAKVILLE, ONTARIO
L6L 5W2
CANADA

Congratulations on your purchase of a Clearwater Chlorinator. You have made a wise decision and you will benefit from your Clearwater for many years to come.

Please take a moment to read through the entire manual before installing your new unit. Your chlorinator must be installed and operated as specified.

Domestic
Registration number 27580 Pest Control Products Act

Table of Contents

	Page No.
Safety Instructions	3
Technical Specifications	4
How your Clearwater Chlorinator Works	5
Cell Life	7
Operating Tips	8
Salt: When and How to Add It	9
Salt Chart	11
Stabilizer Chart	12
Some Tips on Water Chemistry	13
Troubleshooting	14
Chlorinator Maintenance	19

Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS. READ AND FOLLOW ALL INSTRUCTIONS. SAVE ALL INSTRUCTIONS.

WARNING Failure to heed the following warnings can result in permanent injury, or drowning.

ELECTRICAL HAZARD

- To reduce risk of electrical shock
 - Make sure all power to pool equipment area is off prior to any installation or removal of Clearwater components.
 - Replace damaged power pack cord immediately.
 - Do not bury cord. Locate cord to minimize abuse from lawn mowers, hedge trimmers and other equipment.
- Install the power pack at least 3.05 metres (10 feet) from the inside walls of a pool to prevent any possibility of the unit coming in contact with water.
- Your Clearwater chlorinator has been designed with an electronic flow switch. This device automatically switches the chlorinator 'OFF' when the water through the cell stops. To prevent cell damage and personal injury, do not in any way interfere with this system which has been designed for your protection.
- Never plug more than one pump at a time into a 3-pin socket (where fitted) in the base of the power supply.

EQUIPMENT WATER PRESSURE HAZARD

- Always turn pump off prior to installing or removing any Clearwater cell. Your pump and filter system operate under pressure and the pressure must be released before you begin work. Please see your pump and filter owner's manual for further instructions.
- To avoid cell damage, water pressure in the cell must not exceed 200kPa (40psi).

PREVENT CHILD INJURY AND DROWNING

- To reduce the risk of injury, do not permit children to operate or perform maintenance on this product.
- Do not let anyone, especially small children, sit, step, lean, or climb on any equipment installed as part of your pool's operational system. Unless otherwise stated, ALL components of your pool's operational system should be located at least 1 metre (3 feet) from the pool so children cannot use the equipment to gain access and be injured or drown.

WARNING Failure to heed the following warnings could cause damage to pool equipment or personal injury.

- Chlorinator must be installed and operated as specified.
- Scratching or bending plates in cell housing can reduce cell life.

- Power to the LM2 should be turned off before unplugging the cell connectors to prevent cell damage and low voltage sparks.
- Keep the cell terminals protected with a light coating of silicone grease to allow for a positive electric connection. Use of any other type of grease may damage the terminal seals and 'o' rings. Do not immerse these terminals in acid wash solution, and avoid accidental contact with salt water.
- Water above the temperature of 40°C (104°F) flowing through the cell can cause plastic cell to discolour.
- Power pack must not be installed directly above any other heat source such as filter, pump or heater. It must be at least 30 cm (1 foot) from the ground to allow free circulation of air around it. It must not be installed in a closed box. If the power pack is to be installed on a post, then it must be centrally positioned on a flat panel of suitable waterproof material at least 24 cm (10 inches) wide and 44 cm (18 inches) high.
- Check the cell frequently to prevent the accumulation of pool debris that for any reason may have by-passed the pool filter.
- To avoid personal injury when working with pool chemicals, always wear rubber gloves and eye protection and work in a well-ventilated area. Use caution when choosing a location to open and use chemicals as they may damage any surface in which they come in contact.
- The addition of certain chemicals can reduce the effectiveness of chlorine. Always make sure that proper residual chlorine levels are maintained to avoid personal injury.
- This product manufactures chlorine. Individuals with any type of chlorine sensitivity should take the appropriate precautions to avoid injury or illness.
- Turn device off when backwashing filter.

Technical Specifications

Model: LM2-24

Chlorine Output: 17.75 grams/hour

Salt Level: 4000 ppm

Input: 220V, 60Hz AC 2 Amp Max

Output: 16V, 9Amp, DC

Minimum Flow Rate: 42 litres/minute (11 gallons/minute)

Weight: 10 kg (22 lbs)

Dimensions: Cell: 21cm x 7.5cm x 8cm (8 ¼" x 3" x 3¼")

Power Pack: 18cm x 37.5cm x 12.5cm (7 5/8" x 14 ¾" x 4 7/8")

Plumbing: 3.8 cm (1½ inches)

Maximum operating pressure: 200 kPa (40 psi)

How your Clearwater Chlorinator Works

Common salt (sodium chloride) is made up of two elements, sodium and chloride. When your Clearwater LM2-24 is installed, a measured quantity of salt is dissolved in the pool water to make it slightly salty. As part of the daily filtration cycle, the pool water is passed through the Clearwater electrolysis cell to produce chlorine which is dissolved instantly into the water. Your Clearwater also produces ozone in the cell as a by-product.

In simple, non-technical terms, the chlorine instantly starts to destroy bacteria, viruses and algae, and in doing this reverts to dissolved salt. This cycle continues with more new chlorine being produced from the salt water in the electrolysis cell, sanitizing the pool, and changing once more back to dissolved salt.

Everyday, when the Clearwater unit and the filtration system are switched on, dust and debris are trapped by the pool filter and the Clearwater sanitizes the water to make it safe and sparkling clean.

IMPORTANT

To ensure your LM2-24 works at maximum efficiency, regularly check and maintain the chemistry of your pool.

Water Chemistry Readings

Maintain daily levels as determined by testing kit

Free available chlorine: 1.0 - 3.0 ppm

pH: 7.2 – 7.8

Total Alkalinity: 100 – 120 ppm

Calcium Hardness: 200 – 300 ppm

Stabilizer (Cyanuric acid): 30 – 100 ppm (NOTE: Indoor pools do not require chlorine stabilizer)

Salt Concentration: 4000 ppm

NOTE: Check expiry date of the test kit as test results may be inaccurate if used after that date.

Clearwater Model LM2-24 Operation

The chlorine production of the Clearwater LM2-24 is controlled by the number of hours the Clearwater and filtration system are ON, as well as the setting of the output control. The power supply to this unit must be connected to the pump motor switch or automatic timer. The chlorinator functions may only be set when the filtration system is running.

The Clearwater LM2-24 includes a 'Super Chlorinate' feature which automatically super chlorinates the pool for an approximate 24-hour period of pool pump operation.

The Clearwater LM2-24 is also fitted with 3 indicator lights that monitor the operation of the chlorinator, the concentration of salt in the pool, and the water flow.

The LM2-24 is a self cleaning unit. It is designed to require minimum operator maintenance using reverse polarity technology to minimize the scaling of the cell.

Control Panel Functions

On/Off Button

The Clearwater will operate when the pump is turned on. If necessary, the ON/OFF button will switch the LM2-24 on or off. A yellow light appears in the chlorine output indicator window when the unit is on.

Output Button

The output button is used to set the chlorine output of the LM2-24.

Chlorine output is selected by repeatedly pushing this button until maximum is reached on the chlorine output indicator. An extra push of this button will reset the output to minimum.

Super Chlorinate Button

The 'Super Chlorinate' function is used to rapidly add chlorine to the pool.

This feature automatically super chlorinates your pool for approximately 24 hours of pool pump run time.

Backup Battery

The LM2-24 is fitted with a rechargeable battery. If the power is removed, the LM2-24 will retain the output power settings and super chlorinate settings.

(insert display panel picture)

Indicator lights: What they mean

Chlorine Output

A series of six lights indicate the chlorine output setting of the power pack. More lights equals greater chlorine production. **Note:** This setting does not show the actual chlorine reading in the pool. Use of a test kit is required to confirm the salt level or free chlorine reading of pool water.

Chlorine Output – Yellow Light Flashing

The yellow (low output) light flashes for a few minutes during cell reversal (cell self-clean) indicating no output during this time.

Super Chlorinate – Light On

This light indicates that the super chlorinate feature has been selected, it will turn off when the super chlorinate period has ended.

Super Chlorinate – Light Off

Function not selected.

Add Salt – Light On

The 'Add Salt' light will come on at any salt level between 3000ppm and 4000ppm depending on mains voltage and water temperature (below 18°C, 65°F). This is not a fault but a precaution to ensure the salt level is never too low. (See "Salt: When and how to add it"). Note: Operating the LM2-24 at reduced salt levels may shorten the life of the cell.

Add Salt – Light Off

Indicates that the salt level in the pool is correct.

No Flow – Light On

This indicates insufficient water flow in cell, usually caused by the pump not running. The chlorine output will also turn off at this time. Do not leave the device on when the pump is off or when backwashing the filter.

All Lights Off

All lights off indicates the LM2-24 is turned off. Turn unit on. If lights are still off, check the resettable fuse and circuit breaker.

Cell Life

The expected lifespan of a Clearwater cell when sized and maintained appropriately is approximately 5 years in a seasonal climate. However in conditions where there is a high demand for chlorine (high bather load, poor water chemistry, very hot climate) this lifespan may be reduced. When replacing the cell, only use replacement cells having a label that clearly states that it is a replacement cell for the chlorine generating device

Operating Tips

A. Filtration and chlorination system operating periods

Run your filtration and chlorination system for at least 6 to 8 hours per day. During very hot weather it might be necessary to run the system for additional hours, but in winter where pools remain open, the filtration system may be run over a shorter period of time. Shorter periods will help to lengthen the life of the cell electrodes.

B. Chlorine output settings

Start operation of the Clearwater LM2-24 at maximum output. Add salt to the pool if the 'Add Salt' light is showing. Add 1 gram of salt per litre to raise the salt level by 1000ppm. Refer to 'Salt: When and how to add it' and the salt chart. Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit.

C. Free (residual) chlorine reading

The free chlorine residual in the pool should be between 1- 3 ppm. Increasing the daily operating period of the system increases the free chlorine reading, and a shorter operating period reduces the chlorine reading. Likewise, operating the chlorinator at maximum output will produce a higher chlorine reading than operating the chlorinator at a lower setting.

D. Chlorine stabilizer (cyanuric acid) level

The chlorine stabilizer (cyanuric acid) reading should be between 30-100 ppm. This will vary depending on your regional climate. Chlorine stabilizer helps to keep a satisfactory free chlorine reading in hot sunny climates. Extremely hot and sunny climates will require readings at the higher end on the given range. Refer to stabilizer chart. Cyanuric acid prevents rapid destruction of chlorine by the sun's rays. Regulations may exist regarding the use of cyanuric acid; please consult your local authority. NOTE: Cyanuric acid is not needed for indoor pools.

E. pH readings

It is ABSOLUTELY ESSENTIAL that the pH of the pool be maintained in the range of 7.2 – 7.8. The effectiveness of chlorine as a sanitizer is significantly reduced as the pH rises. At a pH of 8.0 nearly all of the chlorine being added to the pool is ineffective, and it will be almost impossible to maintain a satisfactory free chlorine reading.

F. Regular maintenance checks.

Daily:

- Check the free chlorine.
- Check the total alkalinity. Adjust if necessary.
- Check the pH of the water. Adjust if necessary

Weekly:

- Visually check the cell electrodes. Only if necessary, remove the cell and flush with a garden hose to remove any debris that may have passed through the filter and lodged in the cell housing. Avoid inserting objects into the cell which can scratch or bend the cell plates.
- Check the pressure gauge on the filter to see if backwashing is necessary.

Monthly:

- Check the salt concentration of the pool (see 'Salt: When And How To Add It').
- Check the chlorine stabilizer reading. Adjust if necessary.

You should always test the chlorine levels of your pool before each use.

NOTE: Maintaining constantly high levels of salt and chlorine above recommended range can contribute to corrosion of the pool equipment. Salt levels exceeding the recommended concentration can be reduced by diluting the pool water with fresh water.

Do not add pool chemicals directly to the skimmer. This may damage the cell.

G. Spring Start-up

The output of the cell is determined by water temperature, salt level and mains voltage. In the springtime when the water temperature of the pool may be below 18°C (65°F) the Add Salt light may light up. Damage may occur to the Clearwater cell at temperatures below 16°C (60°F). In the springtime when there is very low chlorine demand because of low bather load a manual addition of liquid chlorine (sodium hypochlorite) may be used instead. Alternatively adding salt will increase the conductivity of the water and decrease the impact to the cell. However do not exceed a level of 5000 ppm salt as this may contribute to corrosion of pool equipment. Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit.

Salt: When And How To Add It**When to add salt**

Add salt when indicated on the control panel. The light marked 'Add Salt' functions automatically when extra salt is needed. Note that the 'Add Salt' light may switch on at any salt level between 3000 and 4000 ppm, depending upon the water temperature and mains voltage (see note). This is not a fault but a precaution to ensure that the salt level is never too low.

The salt concentration should normally be around 4000 ppm, but should never be allowed to fall below 3000 ppm, as this can reduce the life of the cell electrodes.

Salt is not lost through evaporation. Salt is lost with the water splashed out of the pool or during backwash. Adding fresh water or rainfall to the pool dilutes the salt concentration. Adding salt may be needed from time to time to maintain an optimum salt level.

NOTE: Even if the salt concentration is around 4000 ppm, the 'Add Salt' light may switch ON if the water temperature drops below 18°C (65°F) or mains supply voltage is too low. In this situation, it may not be possible to set the Chlorine Output to maximum. Addition of more salt to the pool will allow the Chlorine Output to reach maximum settings. If the water temperature is below 18°C (65°F) and the salt is already at 4000 ppm it may be better to keep the Clearwater off until the temperature rises in order to avoid having higher levels of salt. With cold temperatures and low bather load it is not necessary to have the chlorinator on. A manual addition of sodium hypochlorite may be all that is needed.

How much to add

Use a salt test strip to determine salt level in pool water prior to adding any salt. Capture water from elbows depth in a container, then use a test strip in this water sample. Previous regular usage of sodium hypochlorite (liquid chlorine) creates residual salt within the pool and may bring your salt level close to the required 4000 ppm concentration. Only 99.5% pure refined salt (sodium chloride) should be used with the Clearwater chlorinator. Add enough salt to obtain a 4000 ppm concentration.

- 1 gram per litre raises the salt level by 1000 ppm.
- In a NEW pool (where there is no salt residual) of approximately 80 000 litres, eight 40 kg bags of salt are required to reach a 4000 ppm concentration.
- Refer to 'Salt Chart'.

How to add salt

Evenly disperse the proper amount of salt around the perimeter of the pool. Run pump for 4-6 hours. Allow 24 hours for salt to fully dissolve. It will dissolve faster if pump is on. If the 'Add Salt' light is on after 24 hours, test salt level and add necessary salt to obtain a 4000 ppm concentration. Even if the salt level is maintained at 4000 ppm, but water temperature drops below 18° (65°F), the 'Add Salt' light may come on. This is not cause for concern. For further assistance, consult your pool professional or call 1-888-647-4004.

Note: Do not add salt to the skimmer box. Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit

SALT CHART

The following is a chart to determine the amount of salt required to raise a pool to 4000 parts per million

Current Salt Level in Parts Per Million

		0	500	1000	1500	2000	2500	3000	3500
	10 000	40 kg	35 kg	30 kg	25 kg	20 kg	15 kg	10 kg	5 kg
	20 000	80 kg	70 kg	60 kg	50 kg	40 kg	30 kg	20 kg	10 kg
	30 000	120 kg	105 kg	90 kg	75 kg	60 kg	45 kg	30 kg	15 kg
	40 000	160 kg	140 kg	120 kg	100 kg	80 kg	60 kg	40 kg	20 kg
	50 000	200 kg	175 kg	150 kg	125 kg	100 kg	75 kg	50 kg	25 kg
Volume	60 000	240 kg	210 kg	180 kg	150 kg	120 kg	90 kg	60 kg	30 kg
of Water	70 000	280 kg	245 kg	210 kg	175 kg	140 kg	105 kg	70 kg	35 kg
in Litres	80 000	320 kg	280 kg	240 kg	200 kg	160 kg	120 kg	80 kg	40 kg
	90 000	360 kg	315 kg	270 kg	225 kg	180 kg	135 kg	90 kg	45 kg
	100 000	400 kg	350 kg	300 kg	250 kg	200 kg	150 kg	100 kg	50 kg
	110 000	440 kg	385 kg	330 kg	275 kg	220 kg	165 kg	110 kg	55 kg
	120 000	480 kg	420 kg	360 kg	300 kg	240 kg	180 kg	120 kg	60 kg
	130 000	520 kg	455 kg	390 kg	325 kg	260 kg	195 kg	130 kg	65 kg

Note: There may already be some salt present in the water. Be sure to test the salt level prior to adding any.
Do not operate the Clearwater until the salt has dissolved as this will cause damage to the unit.

For more information please contact Zodiac Pool Care Canada at 1888 647 4004

STABILIZER (CYANURIC ACID) CHART

The following is a chart to determine the amount of stabilizer (cyanuric acid) in kg required to raise a pool to 60 parts per million

		Current Stabilizer Level in Parts Per Million							
		0	10	20	30	40	50		
	10 000	0.6 kg	0.5 kg	0.4 kg	0.3 kg	0.2 kg	0.1 kg		
	20 000	1.2 kg	1.0 kg	0.8 kg	0.6 kg	0.4 kg	0.2 kg		
	30 000	1.8 kg	1.5 kg	1.2 kg	0.9 kg	0.6 kg	0.3 kg		
	40 000	2.4 kg	2.0 kg	1.6 kg	1.2 kg	0.8 kg	0.4 kg		
	50 000	3.0 kg	2.5 kg	2.0 kg	1.5 kg	1.0 kg	0.5 kg		
Volume	60 000	3.6 kg	3.0 kg	2.4 kg	1.8 kg	1.2 kg	0.6 kg		
of Water	70 000	4.2 kg	3.5 kg	2.8 kg	2.1 kg	1.4 kg	0.7 kg		
in Litres	80 000	4.8 kg	4.0 kg	3.2 kg	2.4 kg	1.6 kg	0.8 kg		
	90 000	5.4 kg	4.5 kg	3.6 kg	2.7 kg	1.8 kg	0.9 kg		
	100 000	6.0 kg	5.0 kg	4.0 kg	3.0 kg	2.0 kg	1.0 kg		
	110 000	6.6 kg	5.5 kg	4.4 kg	3.3 kg	2.2 kg	1.1 kg		
	120 000	7.2 kg	6.0 kg	4.8 kg	3.6 kg	2.4 kg	1.2 kg		
	130 000	7.8 kg	6.5 kg	5.2 kg	3.9 kg	2.6 kg	1.3 kg		

For more information please contact Zodiac Pool Care Canada at 1888 647 4004

Some Tips on Water Chemistry

How to adjust pH.

A pH range of 7.2 – 7.8 is ideal for maximum comfort and minimum chlorine demand.

Always adjust total alkalinity before adjusting pH.

Low pH (acidic water) leads to stinging eyes and corrosion of open metal fittings. Raise the pH by adding sodium bicarbonate or soda ash. Consult your pool professional regarding which chemical is best for your situation and the proper amount to use. Check the pH after 4 hours of circulation, adjusting as necessary to achieve the proper range.

High pH (alkaline water) leads to clouding of the water and reduces the amount of active chlorine. This means algae and germs can grow. Lower the pH by adding muriatic acid to the pool water. The acid demand indicated by your 4-in-1 test kit will show the amount of acid to use. **WARNING: ALWAYS ADD ACID TO WATER, NEVER WATER TO ACID.**

If your pH remains inconsistent, check your total alkalinity.

Total alkalinity affects pH

Total alkalinity is a measure of the alkaline chemicals in your pool water (e.g. Bicarbonates, carbonates, and hydroxides). It can be thought of as the buffering system necessary to control pH. Low alkalinity can be compared to weak shock absorbers on a car, allowing pH to fluctuate. The pH will be difficult to maintain and staining of pool surfaces may occur when total alkalinity is too low.

Total alkalinity should be in the range of 100-120 ppm. Total alkalinity is often confused with pH, which it affects.

To raise total alkalinity, add pH buffer (sodium bicarbonate) at the rate shown in the manufacturer's instructions to achieve a reading in the 100 – 120 ppm range. 180 g of sodium bicarbonate raises 10,000 litres of pool water by 10 ppm.

To lower the total alkalinity, use muriatic acid. The acid demand chart in your 4-in-1 test kit indicate the necessary amount to add. Adjust as needed until the reading (taken at least 24 hours later) is in the 100-120 ppm range. When total alkalinity is correct, you may need to adjust pH. **WARNING: ALWAYS ADD ACID TO WATER, NEVER WATER TO ACID.**

Use algaecides and phosphate removers

Although not normally needed, algaecides and phosphate removers may be used in conjunction with a Clearwater chlorinator. Consult your pool professional regarding the

presence of phosphates in your local area and always follow manufacturer's instructions for treatment.

The chlorine residual level automatically produced by a Clearwater chlorinator is the best defence against algae and is usually all that is necessary. If algae is observed however, brush spot thoroughly, adjust pH, super-chlorinate with your Clearwater chlorinator or manually shock pool water with either liquid chlorine (sodium hypochlorite). A chlorine residual should be measurable within 24 hours. If not, repeat shock treatment. After shocking, check to ensure that the Clearwater chlorinator is maintaining a residual chlorine level to prevent future algae growth. With extreme algae conditions, manually shocking the pool is the best option.

Note: Overuse of algaecides can lead to a reduction in chlorine residual because algaecides can negatively react with the chlorine produced by the Clearwater chlorinator. When using algaecides, always follow manufacturer's instructions and adjust the output of the Clearwater chlorinator to maintain a residual chlorine level.

The addition of certain chemicals can reduce the effectiveness of chlorine. Always make sure that proper residual chlorine levels are maintained to avoid illness.

Use of sequestering agents

In some areas the total hardness of your source water may be unusually high. High total hardness contributes to scale formation in the pool. Sequestering agents will help keep minerals in solution, preventing this from happening. Consult your pool professional about the use of a sequestering agent.

Troubleshooting

Note: If the chlorinator and pump are running it is normal for a cloud of small bubbles to be produced in the cell, indicating chlorine is also being produced.

Problem A

Water looks clean but no chlorine residual reading.

To test for chlorine residual, switch on the filtration system and adjust the Clearwater to maximum output. After a few hours take a water sample from the pool. Test this water with your test kit. Chlorine residual should measure between 1 and 3 ppm.

REMEDY:

- Adjust total alkalinity to 100-120 ppm.
- Adjust the pH within the range 7.2 – 7.8.
- Make sure your cell is clean.
- Check cyanuric acid (stabilizer) level.
- Increase the setting of the output control.

- Increase the running time of the pump, filter and chlorinator. Make sure that the filter is clean and functioning properly.
- Add salt if indicated by 'Add Salt' light.

Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit.

Use chlorine stabilizer (cyanuric acid) to protect chlorine residual.

This chemical acts as a sun-screen for chlorine and prevents chlorine from being too quickly destroyed by the sun. Chlorine stabilizer is essential to prolong the life of chlorine in the pool water. It should be added following the manufacturer's instructions to achieve a level of 30- 100 ppm depending on geographical climate. Refer to stabilizer chart.

Use of algaecides

Although not normally needed with a Clearwater chlorinator, algaecides may be used. Always follow manufacturer's instructions for treatment. Overdosing the pool with any type of algaecide may reduce residual chlorine measurements/reading. If this occurs, you must manually shock pool water with liquid chlorine (sodium hypochlorite) until a measurable free chlorine residual reading is obtained.

Problem B

Pool green and no chlorine reading

Chlorine is still considered the most effective way of destroying algae and bacteria in your pool water. A chlorine residual of 1 to 3 ppm is considered desirable.

REMEDY:

Superchlorinate or manually shock the pool with sodium hypochlorite. This will raise the chlorine residual to a very high level for a short period of time, and reduce chlorine demand.

1. Superchlorinate with the Clearwater chlorinator:

- i) Backwash the filter.
- ii) Adjust the pH to within the range 7.2 – 7.8. See 'Tips on Water Chemistry'.
- iii) Press the button marked 'Super Chlorinate'. The Clearwater automatically increases its output and runs for approx. 24 hours of pool pump time.
- iv) After 24 hours, backwash the filter.
- v) Re-adjust the pH to 7.2 – 7.8.
- vi) Check the chlorine reading.
- vii) If the chlorine reading is too low, repeat steps (iii) to (vi) until the chlorine reading is satisfactory.

2. Manually shock with chlorine or oxidizing agents:

- i) Backwash the filter.
- ii) Adjust the pH to within the range 7.2 – 7.8 (See 'Tips on Water Chemistry').

- iii) Follow instructions of superchlorinating product being employed.
- iv) After shock dosing, re-adjust the pH to within the range of 7.2 – 7.8 and check the chlorine level before using the pool. The chlorine residual should be 1 – 3 ppm.

Problem C

Chlorine odour

CAUSE: Not enough free chlorine.

Surprisingly, the problem here is not too much chlorine as many imagine. Chloramines form by the bonding of chlorine with amines from sweat and other sources. These chloramines can create a chlorine odour and can also cause eye and skin irritation. Free chlorine does not smell (up to 10 ppm concentration).

REMEDY:

Same as problem B.

Problem D

Slimy walls of pool

CAUSE: Combined algae and bacteria growth.

REMEDY:

Brush down the affected walls and follow remedy for Problem B, manually shocking pool with sodium hypochlorite.

Problem E

Eye and/or skin irritation

CAUSE: Improper water balance.

REMEDY:

Balance the water (See 'Tips on Water Chemistry').

Problem F

Scale formation on pool equipment

To clean the deposit (scale) from the cell, see Chlorinator Maintenance section.

CAUSE 1: Incorrect pH and hard water.

REMEDY:

Adjust the pH to within the range 7.2 – 7.8 (See ‘Tips on Water Chemistry’).

CAUSE 2: High total hardness.

REMEDY:

Dilute pool with fresh water. Consult your pool professional regarding use of a sequestering agent.

Problem G

Chlorine Output will not reach maximum – Add Salt light may also be on

CAUSE 1: Low incoming voltage.

REMEDY:

Confirm Clearwater is wired to 220V. If wired to 220V but incoming voltage is less due to location (rural areas for example), raising the salt level will compensate.

Add salt. (See ‘Salt: When and How to Add it’). If adding salt to compensate for low temperature, do not exceed 5000 ppm salt as it may contribute to corrosion of the pool equipment. Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit.

CAUSE 2: Salt level below 4000 ppm or water temperature is below 18°C (65 °F).

REMEDY:

Add salt. (See ‘Salt: When and How to Add it’). If adding salt to compensate for low temperature, do not exceed 5000 ppm salt as it may contribute to corrosion of the pool equipment. Do not operate the Clearwater until all the salt has dissolved as this will cause damage to the unit.

CAUSE 3: Cell reversing (self-cleaning).

REMEDY:

If the cell is reversing the yellow light on the Chlorine Output indicator will flash. Wait approximately three minutes and the output should return to normal.

CAUSE 4: Cell electrodes may be damaged.

REMEDY:

Replace cell. When replacing the cell, only use replacement cells having a label that clearly states that it is a replacement cell for the chlorine generating device Clearwater

Salt Chlorinator Model LM2-24, REGISTRATION NUMBER 27580, PEST CONTROL PRODUCTS ACT.

Problem H

No Flow light on

CAUSE1: Insufficient water flow through the cell.

REMEDY:

Ensure sufficient water flow through chlorinator cell. Verify that the filter and pump are on. Flow may be restricted if the filter needs backwashing. A pocket of air trapped in the top of the cell confirms low water flow through the cell.

WARNING: Operating Clearwater Salt Chlorinator Model LM2-24 without water flow through the cell can cause a build up of flammable gases which can result in FIRE OR EXPLOSION.

CAUSE 2: Sensor disconnected.

REMEDY:

Make sure that the sensor lead from the power pack to the cell is attached at the cell (small clip lead).

Problem I

Chlorinator stops working, all lights OFF

CAUSE 1: Unit turned off.

REMEDY:

Push ON/Off button. A yellow light in the 'Chlorine Output' indicator window is present when the unit is on.

CAUSE 2: Mains power removed or blown fuse.

REMEDY:

Check mains power source and fuse.

Resetting the Fuse

Turn off all power to the Clearwater power pack. The resettable fuse is located above the power cord on the bottom rear of the unit. If the fuse is blown (popped with white area exposed), push to reset. Restore power to unit.

Mains power supply.

Your Clearwater chlorinator must be connected to a properly grounded electrical power socket, or power source.

Problem J

Chlorine level is too high

CAUSE 1: Chlorinator is manufacturing too much chlorine.

REMEDY 1:

Use the output button to reduce setting. Retest chlorine daily until proper level is attained.

REMEDY 2:

Manually turn chlorinator off. The LM2-24 uses a smart switch that turns the chlorinator on automatically with each pump cycle. If longer periods of zero chlorine output are required, disconnect the blue sensor clip on cell. (Red 'No Flow' light will illuminate once chlorine production has stopped.) Sensor clip must be reconnected for chlorine production to begin.

Chlorinator Maintenance

How to clean your cell.

In unusual situations, the self cleaning electrodes may benefit from occasional manual cleaning to remove scale build-up as the result of having very "hard" water or continuous high pH conditions, which can occur with new plaster finishes.

1. Switch off the filter pump and chlorinator, close necessary valves.

Note: Always turn pump off prior to installing or removing any Clearwater cell. Your pump/filter system is operated under pressure and pressure must be released before you begin. Open the air relief valve on your pool filter to release the pressure in the system.

2. Unplug the leads from the cell terminals.
3. Undo the two barrel unions joining the cell housing to the pool filtration system and carefully remove the cell housing. Lay the housing upside down on a flat surface with the inlet ports on top.

(Insert picture of cell)

4. Mix cleaning solution in a suitable plastic vessel by adding one part of hydrochloric (muriatic) acid to ten parts water. **Note: To avoid splash, always ADD MURIATIC ACID TO WATER rather than water to muriatic acid. Solutions stronger than 1:10 will damage cell and void warranty.** Pour the cleaning mixture into the upturned cell housing until the electrodes are completely covered. Allow the cleaning solution to dissolve the calcium deposits for approximately 5 minutes. When the electrodes are clean, pour the cleaning solution and the calcium residue out of the cell housing into a bucket of water. The cleaning solution containing muriatic acid must be disposed of according to federal, provincial or local regulations.

Note: Never mix chemicals together. Always rinse bucket and drain area after cleaning cell.


To avoid personal injury when working with pool chemicals, always wear rubber gloves and eye protection and work in a well ventilated area. Use caution when choosing a location to open and use chemicals as they may damage any surface in which they come in contact.

5. Repeat the procedure if necessary. Take care to avoid splashing the cell terminals and other equipment with the acidic cleaning solution. Wash down any spills with plenty of fresh water.
6. Rinse the electrodes in clean water and refit the cell and housing to the filtration system. Tighten the barrel union connectors to prevent leaks.
7. Replace the electrical connectors after drying and smearing lightly with silicone grease.
8. Reset valves and switches. Turn pump and chlorinator on.
9. Confirm chlorine output and settings on the power pack.

Your Clearwater Chlorinator has been designed with an electronic flow switch. This device automatically switches the chlorinator off when water through the cell stops. To prevent damage and personal injury, do not in any way interfere with this system that has been designed for your protection.

Damage caused by insects

The case of the Clearwater power pack has small vents to allow internal components to remain cool in hot weather. Sometimes small insects may enter the case of the power pack, and this can cause damage to the internal electrical components.



LM2 Display Panel

21-NOV-2003

Clearwater Salt Chlorinator Model LM2-24

For Residential Pools

Installation Instructions

IMPORTANT! PLEASE READ THESE INSTRUCTIONS COMPLETELY BEFORE INSTALLING OR OPERATING THE CLEARWATER SALT CHLORINATOR.

RETAIN THIS MANUAL FOR FUTURE REFERENCE.

SUPPLY POOL OWNER WITH COPY OF THE OWNER'S MANUAL. THIS WILL REDUCE CUSTOMER DIFFICULTIES CAUSED BY LACK OF POOL CARE KNOWLEDGE. OWNER'S MANUAL CONTAINS INSTRUCTIONS ON USE AND WARRANTY INFORMATION.

THE CLEARWATER CHLORINATOR MODEL LM2-24 HAS BEEN TESTED AND APPROVED TO CSA-22.2.

MAXIMUM OUTPUT OF HYPOCHLOROUS ACID EQUIVALENT TO 0.426 KG OF FREE CHLORINE PER DAY OR 17.75 GRAMS PER HOUR.

DOMESTIC
REGISTRATION NUMBER 27580 PEST CONTROL PRODUCTS ACT

PRECAUTIONS:

WHEN INSTALLING AND USING THIS ELECTRICAL EQUIPMENT, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

1. READ AND FOLLOW THESE INSTRUCTIONS
2. DISCONNECT ALL AC POWER DURING INSTALLATION
3. TO REDUCE THE RISK OF INJURY, DO NOT PERMIT CHILDREN TO USE THIS PRODUCT UNLESS CLOSELY SUPERVISED AT ALL TIMES.
4. SERVICE SHOULD ONLY BE ATTEMPTED BY A QUALIFIED POOL PROFESSIONAL.
5. CONNECT TO A CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER. (GFCI)
6. TO REDUCE THE RISK OF ELECTRIC SHOCK, THE CLEARWATER POWER PACK SHOULD BE GROUNDED. FOR THE LOCATION OF THE GROUNDING TERMINAL PLEASE REFER TO WIRING DIAGRAM.
7. POWER SUPPLY MUST BE INTERCONNECTED WITH POOL PUMP MOTOR POWER SOURCE OR AUTOMATIC TIMER.
8. DO NOT OPERATE THE CLEARWATER WITHOUT WATER CIRCULATION.
9. SAVE THESE INSTRUCTIONS.

Technical Specifications

Model: LM2-24

Chlorine Output: 17.75 grams/hour

Salt Level: 4000 ppm

Input: 220V, 60Hz AC 2 Amp Max

Output: 16V, 9Amp, DC

Minimum Flow Rate: 42 litres/minute (11 gallons/minute)

Weight: 10 kg (22 lbs)

Dimensions: Cell: 21cm x 7.5cm x 8cm (8 ¼" x 3" x 3¼")

Power Pack: 18cm x 37.5cm x 12.5cm (7 5/8" x 14 ¾" x 4 7/8")

Plumbing: 3.8 cm (1½ inches)

1. Salt

Use refined pure salt (sodium chloride), avoid additives such as iodine. Add salt at the rate of 4 kg per 1000 litres to raise the salt level from 0 to 4000 ppm. For existing pools with a residual of sodium chloride from chlorine use, determine the current level of salt in the pool then add enough salt to raise the level to 4000 ppm. 1 gram per litre (or 1 kg per 1000 litres) raises the salt level 1000 ppm. Refer to Salt Chart in Owner's Manual for further detail.

Distribute the salt evenly at various positions in the pool. Do not pour into skimmer box. The pump may be turned on to circulate the water and help the salt dissolve. **Note:** do not operate the Clearwater before the salt has dissolved, this will cause damage to the unit. After all the salt has dissolved, set the chlorine output control to maximum. If the output light reaches the maximum level, the salt level is correct.

Note that the chlorinator output depends on salt concentration, water temperature, and mains power voltage. The nominal standard values of 4000 ppm salt, 27 °C (80° F) water temperature, and correct mains voltage, will provide maximum output. If any one or more of these three variables are less than the standard values, the output may be less.

2. Install the cell

- a) It is very important that the Clearwater is the last piece of equipment before the pool. If it is not, the chlorine will corrode other equipment. It is also extremely unsafe for the gases produced by the chlorinator to travel through a filter or heater.
- b) The cell must be horizontal with the unions facing downward. The cell must be level in order for the flow sensor to function properly.
- c) Note that the water can flow through the cell in either direction.
- d) Glueing: The cell unions are moulded ABS polymer. They can be glued to PVC using PVC cement. First clean both surfaces with solvent cleaner then apply glue to both surfaces. Assemble glued joint and hold in place for at least 30 seconds. Allow 24 hours to set before turning on the circulation system.

Water pressure in the cell must not exceed 200kPa (40 psi). Temperature of water in cell must not exceed 40°C (104° F).


Do not fit isolating valves at both ends of cell. Cell will break if both valves are closed

3. Install the power pack

Determine the proper area to mount the power pack:

- Position at least 1 metre horizontally away from pool or a hot tub.
- Place power pack close enough to the cell for the cell leads to reach. There is 1.8 metres (6 feet) of cell lead. **DO NOT EXTEND THE CELL LEADS.**
- Power pack must not be installed directly above any other heat source such as filter, pump or heater. It must be at least 30 cm (1 foot) from the ground to allow free circulation of air around it.
- Do not enclose the power pack in a box.
- A shaded position away from rain and direct sunlight is preferable, though not essential.

Use the template provided to fit up to 2 mounting screws (supplied) to a wall or post. (If the power pack is to be installed on a post, first install on a flat panel of suitable waterproof material at least 24 cm (9.45 inches) wide by 44 cm (17.32 inches) high then attach to post.



4. Connecting the power pack to the cell

Connect the blue sensor wire clip to the blue sensor terminal and the other 2 wires to either terminal on the cell. It does not matter which one goes where. Check that the terminals are a snug fit.

Keep the cell terminals protected with a light coating of silicone grease to allow for a positive electric connection. Use of any other type of grease may damage the terminal seals and 'o' rings.

5. Connecting to power supply

- a) The LM2-24 is a 220 Volt unit and must be wired to a 220 Volt source. If it is wired to 110 Volts it will not produce enough power to produce chlorine.
- b) Use #12/3 insulated wire and conduit.
- c) Connect the 220V wires to the first two terminals. It does not matter which of the two terminals but they must be connected to the two load terminals. (Refer to wiring diagram.) Connect ground wire to ground terminal (fourth terminal). **Note:** the third terminal is a spare.
- d) Wire power pack to pool pump power source. The power supply must be connected to the pump motor switch or automatic timer.

(insert wiring diagram)

6. Initial start-up

After waiting 24 hours to allow the PVC glue on the cell fittings to fully set, and making sure that all the salt has dissolved in the pool water, switch on the pump and chlorinator.

Add salt if necessary. Do not operate the Clearwater until the salt has dissolved as this will cause damage to the unit.

7. Safety features

The 'Chlorine Output' lights indicate that the chlorinator is operating correctly and producing chlorine. In the event of hydrogen gas accumulation in the cell housing (for example, when the plumbing valve settings are positioned incorrectly), the chlorinator will cease producing chlorine for safety reasons. The pool pump will continue to operate as normal. (See Safety Test).

The 'Add Salt' light warns the pool operator that the salt concentration in the pool has dropped below a preset critical value. More salt should be added. See the accompanying Owner's Manual for guidelines as to the addition of salt. **Note:** the 'Add Salt' light may activate if the water temperature of the pool drops to temperatures below 18°C (65°F) or if the cell is damaged or needs replacement. Consult Zodiac Pool Care or your local Clearwater dealer for details.

Safety test

It is essential that the flow failure system be tested by the following method. Switch on the pump and chlorinator, and adjust the chlorine output to maximum. Disconnect the blue sensor lead clip from the terminal pin at the end of the cell. The red 'Low Flow' light should come on and the 'Chlorine Output' lights will drop to minimum, yellow light, showing that no chlorine is being produced.

This check should confirm that the flow failure system is operating correctly.

Reconnect the sensor lead clip to the terminal pin which will cause the chlorinator to resume normal operation. Do not continue to operate the chlorinator if the test of the flow failure system indicates a fault. Contact Zodiac Pool Care for advice.


For more information talk to your local Clearwater dealer or telephone Zodiac Pool Care Canada:

Zodiac Pool Care Canada
2115 South Service Road West Unit 3
Oakville, Ontario
L6L 5W2
(905) 825-5439
1 888 647-4004

Made in Australia by Clearwater Australia Pty Ltd.

NOTICE TO USER: This pest control product is to be used only in accordance with the directions on the label. It is an offence under the Pest Control Products Act to use this product in a way that is inconsistent with the directions on the label. The user assumes the risk to persons or property that arises from any such use of this product.

Clearwater LM2-24 Wiring Diagram



Please note:
Power pack must be wired to pump switch terminals and must be installed to a 220 volt connection.

This label transcript service is offered by the Pest Management Regulatory Agency to provide efficient searching for label information. This service and this information do not replace the official hard-copy label. The PMRA does not provide any guarantee or assurance that the information obtained through this service is accurate, current or correct, and is therefore not liable for any loss resulting, directly or indirectly, from reliance upon this service.