

98.04.29

VISION

Above-Ground

Pool Water Purifier

MODEL: VPG SEASONAL UNIT

DOMESTIC

REPLACE EVERY SEASON:

READ THE LABEL AND OWNER'S MANUAL BEFORE USING

To assist in controlling bacteria and algae growth this device will augment bactericidal and algicidal activity of primary disinfectants such as chlorine in swimming pools and spas. A minimum of 0.6 ppm of free available chlorine must be maintained.

WARNING: Staining of pool surfaces may occur due to deposits of copper salts. Excessive levels of copper will increase the probability of this occurrence.

Fountainhead Technologies, Inc.
501 Valley St.
Providence, RI 02908

REG. NO. 24902

VISION

Above-Ground Pool Water Purifier

DOMESTIC

VISION

Above-Ground Pool Water Purifier

MODEL VPG SEASONAL UNIT

OWNER'S MANUAL

ASSEMBLY
OPERATION
REPAIR PARTS

REGISTRATION NUMBER 24902

PEST CONTROL PRODUCTS ACT

FOR ABOVE GROUND SWIMMING
POOLS BETWEEN 19,000 - 64,400 L
(4,200 AND 14,200 IMPL. GALLONS)

CAUTION:

READ THE LABEL AND OWNER'S MANUAL CAREFULLY BEFORE USING. Check for missing parts by reviewing the Repair Parts List in the back of this book. Keep this owner's manual for future reference.

Fountainhead Technologies, Inc.
501 Valley Street
Providence RI 02908

REGISTRATION NUMBER 24902

PEST CONTROL PRODUCTS ACT

If your retailer does not have VISION products, please call us at 1-800-338-1013 or fill out and return the reorder card included with this manual.

HOW TO ORDER REPAIR PARTS

If you find any of the parts missing or defective or if you cannot identify a problem, do not take the package or any part of the package back to the place of purchase. Instead, contact: 1-800-338-1013.

When ordering repair parts always give the following information: Part Number, Part Description, Name of Item, Model Number.

WARNING

VISION IS DESIGNED FOR ABOVE GROUND SWIMMING POOLS ONLY. NOT FOR HOUSE-HOLD USE.

1. START-UP INSTRUCTIONS

Before starting up a new VISION seasonal unit, clean debris and algae out of pool and equipment.

IMPORTANT:

Do not install VISION until the pool water is chemically balanced.

A. Balance Pool Water

All swimming pools require properly balanced water.

1. PH 7.2-7.8
2. Calcium Hardness 200-300 ppm
3. Total Alkalinity 80-120 ppm

NOTE: Consult your dealer for specific water balance instructions.

B. Installation (FIG. 1)

1. Disconnect the return line from the filter.
2. Attach one end of the enclosed 1-1/2" (3.80 cm) hose to the filter outlet and the other end to the inlet of the purifier.

NOTE: If the filter outlet accepts only 1-1/4" (3,20cm) hose, use the enclosed hose reducer to properly attach the 1-1/2" (3,80cm) hose the filter.

3. Attach the return line to the outlet of the purifier.

C. Superchlorinate ("shock") the pool.

On the first day, super-chlorinate following label instructions of the super-chlorination product employed. This will burn off contaminants and activate the purifier.

D. Activate VISION

1. Run the pump and filter system 24 hours per day for four days. Thereafter, run the pump and filter system 8-12 hours per day depending on bathing load and environmental conditions.

- E. Maintain 1-3 ppm residual chlorine level throughout the 4-day activation period.
- F. Allow the free chlorine residual to drop to - but not below - 0.6 ppm.
- G. Follow the maintenance instructions in this manual.

NOTE: REPLACE SEASONAL UNIT AFTER ONE SEASON OR EVERY SIX MONTHS
 Each VISION seasonal unit will effectively help your pool water pure, clean and odor free for up to 6 months. The 6 month activation period begins when water has passed through the unit. The briquette has been submerged in water. Once the unit has been activated it cannot be deactivated and stored for use at a later time. REMEMBER to replace the unit on a timely basis to ensure efficient pool water purification.

2. PURIFIER COMPATIBILITY

Avoid using VISION seasonal pool water purifier with the following:

Copper-based algaecides

Bromine or bromide chemicals

3. POOL WATER MAINTENANCE

a. ingredients

. VISION seasonal unit . Chlorine* . pH and Total Alkalinity adjusting chemicals

. Total Hardness increaser (if needed) . Water test Kit . Cyanuric Acid.

NOTE: Once the 4-day activation period is completed, allow the free chlorine residual to drop to - but not below - 0.6 ppm free available chlorine.

*Several delivery methods exist for chlorine. These include granules, tablets, liquid, electrical chlorine generators, etc. Each method has its own merit. Consult your dealer.

WHEN	WHAT TO DO
EVERY DAY	RUN PUMP AND OPERATE FILTER SYSTEM AT LEAST 8 HOURS DAILY
ONCE A WEEK	BALANCE pH AND TOTAL ALKALINITY.

TWICE A WEEK	CHECK CHLORINE RESIDUAL. ADD CHLORINE TO MAINTAIN 0.6 ppm FREE AVAILABLE CHLORINE.
AS NEEDED	IF THE POOL WATER STARTS TO LOOK HAZY, SUPER-CHLORINATE (SHOCK) FOLLOWING LABEL INSTRUCTIONS OF THE SUPER-CHLORINATION PRODUCT EMPLOYED. (ADD CYANURIC ACID TO MAINTAIN 50 ppm).

NOTE: AFTER HEAVY USE OR RAINSTORMS, ADDITIONAL SUPER-CHLORINATION TREATMENTS ARE RECOMMENDED.

If your retailer does not have VISION products, please call us at 1-800-338-1013 or fill out and return the reorder card at the back of this manual.

REPAIR PARTS

KEY NO.	PART NO.	QTY.	DESCRIPTION
1	56010	2	HOSE CLAMPS
2	49031	1	HOSE (3'-2" [96 CM] LONG 1-1/2" [3,80 CM] DIA.)
3	56037	1	SEASONAL PURIFIER
4	56039	1	HOSE REDUCER
*	91267	1	REORDER INFORMATION CARD
*	94173E	1	OWNER'S MANUAL

REPLACE YOUR VISION SEASONAL UNIT
EVERY 6 MONTHS

This label transcript service is offered by the Pest Management Regulatory Agency to provide efficient searching for label information. This service and this information do not replace the official hard-copy label. The PMRA does not provide any

guarantee or assurance that the information obtained through this service is accurate, current or correct, and is therefore not liable for any loss resulting, directly or indirectly, from reliance upon this service.

+))