

2017-0258
2017-07-27

C-UNION JACK
ANTIFOULING PAINT (RED)

DOMESTIC

SUSPENSION

KEEP OUT OF REACH OF CHILDREN

IMPORTANT

READ THE LABEL BEFORE USING.

FOR USE ON BOATS ONLY.

SKIN AND EYE IRRITANT.

NOT FOR SPRAY USE.

ONLY BRUSH OR ROLLER APPLICATION.

GUARANTEE:

copper, present as cuprous oxide 17.86%

REGISTRATION NO. 22728

PEST CONTROL PRODUCTS ACT

3.78 L

CAUTION

FLAMMABLE

DANGER

POISON

International Paint LLC, 6001 Antoine Drive, Houston, Texas 77091 USA
713-682-1711

C-UNION JACK
Antifouling Paint

DIRECTIONS FOR USE:

A moderate priced antifouling that will provide up to 12 months performance.

OVERCOATING EXISTING ANTIFOULINGS: Remove all loose paint, dirt, grease, and marine growth. Wash down with fresh water and allow to dry before painting. Surface must be clean and dry. Prime bare areas with appropriate system.

NEW WORK:

Steel: Prepare steel by blasting to SSPC-SP10 or SA2 ½ near white metal. Apply multiple coats of Interprotect 2000E/2001E* to achieve 10 mils d.f.t. Apply two coats of C-Union Jack observing overcoating times.

Wood: Sand wood and wipe surface clean. Thin first coat of C-Union Jack 20% with Interlux Brush Ease 433. Apply second coat unthinned observing overcoating times.

Fiberglass: Wipe down fiberglass with Interlux Fiberglass Solvent Wash 202. Apply 1 thin coat of Interlux Fiberglass Primer AL200. Overcoat primer within 2-3 hours, no more, no less. Apply second coat of C-Union Jack observing overcoating times. For osmosis repair and prevention, use the Interlux Interprotect System.

Aluminum: Contact International Paint for the recommended paint system.

IMPORTANT: C-Union Jack contains copper (which reacts with aluminum). Regular inspection of primer is required to ensure film integrity.

*The first coat of C-Union Jack should be applied to the last coat of Interprotect 2000E/2001E while it is still tacky to the thumbprint method.

APPLICATION: STIR THOROUGHLY. Apply by brush or roller at least 2 unthinned heavy coats of C-Union Jack. For best results, 3 coats are recommended.

COVERAGE: 11.0 m² per litre at 50 microns d.f.t. per coat

CLEAN-UP: Interlux Special Thinner 216

DRYING: Touch dry: 3 hours

OVERCOATING TIME: Recommended minimum 4 hours, maximum 5 days

IMMERSION: Minimum 8 hours, maximum 5 days**

**C-Union Jack should be immersed as soon as possible after application, preferably within 24 hours, 5 days maximum, only in cool, sunless conditions.

N.B.: These are guidelines only. Temperature and humidity affect cure time.

DO NOT place the painted parts in water after painting until the paint is fully cured (see recommended times on the label). It is recommended that you prevent paint chips or dust caused by removing paint from entering water.

NOTICE TO USER: This control product is to be used only in accordance with the directions on the label. It is an offense under the *Pest Control Products Act* to use this product in a way that is inconsistent with the directions on the label. The user assumes the risk to persons or property that arises from any such use of this product.

ENVIRONMENTAL HAZARDS: Toxic to aquatic organisms. Do not contaminate water by spillage, cleaning of equipment or disposal of wastes. Do not allow chips or dust generated during paint removal to enter water.

DISPOSAL: Do not re-use container for any purpose. Dispose of empty container and paint debris in accordance with provincial requirements. For information on the disposal of unused, unwanted product, and the clean-up of spills, contact the manufacturer or the Provincial Regulatory Agency.

PRECAUTIONS: Keep away from heat, sparks and flame. Vapours heavier than air cause health and explosion hazards. Keep containers tightly closed when not in use. Avoid contact with eyes, skin and clothing. Do not breathe vapours. Wear chemical resistant gloves, goggles and footwear, and chemical resistant clothing including hood or hat at all times during handling and application.

- KEEP OUT OF REACH OF CHILDREN - Handle with care and mix carefully -
When using, do not eat, drink or smoke - Take a shower immediately after work -
Wear freshly laundered clothes daily - Wash hands before eating, drinking, chewing gum, using tobacco or using the toilet - Store and wash all protective clothing separately from household laundry - Wash protective clothing in detergent and hot water before reuse - Use only in well ventilated areas.

FIRST AID: IF IN EYES: Hold eye open and rinse slowly and gently with water for 15-20 minutes. Remove contact lenses, if present, after the first 5 minutes, then continue rinsing eye. Call a poison control centre or doctor for treatment advice. IF ON SKIN OR CLOTHING: Take off contaminated clothing. Rinse skin immediately with plenty of water for 15-20 minutes. Call a poison control centre or doctor for treatment advice. IF INHALED: Move person to fresh air. If person is not breathing, call 911 or an ambulance, then give artificial respiration, preferably by mouth-to-mouth, if possible. Call a poison control centre or doctor for further treatment advice. IF SWALLOWED: Call a poison control centre or doctor immediately for treatment advice. Have a person sip a glass of water if able to swallow. Do not induce vomiting unless told to do so by a poison control centre or doctor. Do not give anything by mouth to an unconscious person. Take container, label or product name and Pest Control Product Registration Number with you when seeking medical attention.

TOXICOLOGICAL INFORMATION: Ingestion (drinking) of this product could cause serious injury or death. There is no antidote for solvent ingestion. Treat symptomatically.

EPA EST. NO. 2693-NJ-1

NOT REGISTERED FOR USE IN THE UNITED STATES OF AMERICA